



P164 RDS Encoder User Manual

Firmware version 2.2e




Table of Contents

1	Introduction	3
1.1	Main Highlights	3
1.2	Other Features	3
2	Technical Specifications	4
2.1	Block Diagram	5
3	Physical Description	6
3.1	Front Panel	6
3.2	Rear Panel	6
3.3	Board Layout	7
4	Installation and Setting-up	8
4.1	Connection	8
4.2	Controls on the Board	9
4.3	Power Supply	9
4.4	Windows Control Software - First Steps	10
4.5	Level and Phase Adjustment	11
4.6	Setting Basic RDS Data	13
5	RDS Services and Features	15
5.1	Broadcast Automation System Link-up	15
5.2	Dynamic PS	17
5.3	Alternative Frequencies	18
5.4	Enhanced Other Networks Information (EON) Setup	20
5.5	Weekly Scheduling	21
5.6	RDS2 Subcarrier Configuration and Station Logo	22
6	Communication Ports	24
6.1	Overview	24
6.2	USB Connection	24
6.3	Ethernet Connection	25
6.4	Port Access Control	29
6.5	Working with a Terminal Application	30
6.6	Command Interpreter	31
6.7	Additional Information	32
7	List of Commands	34
7.1	Command Summary	34
7.2	Basic Commands	37
7.3	EON Commands	43
7.4	Messages Commands	44
7.5	Scheduling Commands	45
7.6	System Commands	46
7.7	Ethernet Configuration Commands	48
7.8	Advanced Commands	49
7.9	Memory Organization	54
7.10	Dynamic PS 1 and Dynamic PS 2 Summary	54
8	Further Features	55
9	Universal Encoder Communication Protocol (UECP)	57
9.1	UECP Implementation	57
9.2	Traffic Message Channel (TMC) Application Notes	60
10	Annexes	61
10.1	Character Set and Code-Table Conversions	61
10.2	RDS Group Format	62
10.3	Installation Essential Checklist	65
10.4	Troubleshooting	66

1 Introduction

The P164 RDS Encoder is an attractive choice to all radio stations which don't want to burden their budget but still need a flexible RDS encoder with support of all common data formats and RDS services. Ultra-compact design based on DSP technology ensures high reliability and gives the user many advanced features while maintaining low acquisition costs. The system is scalable from small local stations to large broadcast networks.

Some features are unique: remote output monitoring down to the bit level, direct conversion of XML tagging data to Radiotext Plus, port multiplication thru Windows control software and several others. Due to support of additional RDS2 data-stream, the P164 is ready for future enhancements of the FM broadcast standards.

1.1 Main Highlights

- Fully dynamic stand-alone FM broadcast RDS encoder with two independent communication ports
- USB connectivity for local settings and maintenance purposes
- Ethernet connectivity for linking with Windows application and broadcast automation system
- Control interface supports all common communication protocols, incl. ASCII and UECP
- Excellent compatibility with broadcast automation systems
- Text features include dynamic PS, parsing, scrolling, tagging, fixed messages and scheduling
- Supports remote output monitoring and station logo ^{*)}
- Two switchable subcarrier configurations (RDS or RDS2)
- Simply to use

^{*)} Note: Current receivers may not fully support the RDS2.

1.2 Other Features

- Direct digital RDS signal synthesis; compliant with EN 50067 / IEC 62106
- Six switchable program sets (with optional PSN setting)
- Bypass relay, high reliability
- Switchable MPX loophrough mode (Loop/Side)
- Internal real-time clock incl. backup battery
- Compatible with P132 family



CE conformance notice:

This device complies with the requirements of the EEC Council CE marking and EMC directives.
Harmonized standards applied: EN 55032, EN 55024.

Please read this manual and familiarize yourself with the controls before attempting to use this equipment.

Where not otherwise indicated, any information mentioned in relation to the **RDS** (Radio Data System) applies in full also to the **RBDS** (Radio Broadcast Data System).

The equipment has been thoroughly tested and found to be in proper operating condition when shipped. The manufacturer is not liable for any damages, including but not limited to, lost profits, lost savings, or other incidental or consequential damages arising out of the use of this product.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or information storage and retrieval systems, for any purpose other than the purchaser's personal use.

Information in this document is subject to change without notice.

If you have any questions or comments regarding this document, please contact us via email.
We welcome your feedback.

Revision 2024-03-24
Copyright © 2024 PIRA Digital s.r.o.





2 Technical Specifications

Parameter	Condition	Value
General		
Supply voltage		12 V DC stabilized
Supply current		150 mA
Signal connectors		unbalanced BNC
Data connectors		1x USB (Port 1), 1x Ethernet (Port 2)
Network protocols supported		HTTP, TCP, UDP, DHCP, DNS
Recommended Ethernet cable type		F/UTP Cat 5e
USB communication speed		software switchable 1200, 2400, 4800, 9600, 19200 bps
USB communication mode		1 stop bit, 8 data bits, no parity, (no flow control), ASCII or UECF (SPB 490)
TA switching		software or input on the board
TA/EON1TA switch input		TTL with 10 k Ω pull-up, level or falling edge activated
Main program sets		6
Program set switching		ASCII command, UECF command or input on the board
Program switch input		TTL with 10 k Ω pull-up, level controlled
RDS Services directly supported		PI, PS, PTY, TP, AF, TA, DI, M/S, RT, RT+ TMC, EON, PTYN, ECC, LIC, IH, CT, ODA
RDS signal		
Subcarrier configuration (switchable)	RDS	57 kHz
	RDS2	57 kHz and 66.5 kHz
Subcarrier bandwidth		\pm 2.4 kHz (50 dBc)
Output level adjust		0.0 to 4.0 V p-p in 256 steps
Phase shift adjust	stereo broadcast	Full range, in 9.5 deg. steps
Audio/MPX/Pilot input		
Recommended load impedance	mono	< 10 k Ω
	stereo MPX	< 2 k Ω
Recommended MPX voltage		1.3 - 8.0 V p-p
Passthrough voltage gain	2 Hz - 100 kHz	1 (0 dB)
Pilot tone level		min. 120 mV p-p
- recommended FM deviation		6.8 kHz
Pilot PLL capture range		8 Hz
Pilot frequency required	stereo broadcast	19000 Hz \pm 2 Hz
Output		
Output impedance		100 Ω
Recommended load impedance		> 70 Ω , < 1 nF, no DC offset
Max. output voltage (RDS + MPX)		9.0 V p-p
Recommended RDS level		3 - 11 % of MPX


Notes: *p-p* - peak-to-peak value
The unit can operate with mono transmitter as well.

2.1 Block Diagram



3 Physical Description

3.1 Front Panel




Connector or element	Description
TA/RDS2	This LED blinks when TA (Traffic Announcement) is ON. It is constantly lit if the RDS2 subcarrier configuration is enabled.
PILOT	Indicates if external pilot synchronization is active. Blinks if the pilot frequency is out of specs.
OPERATION	Blinks shortly once per second if the encoder is operating and ready. Indicates incoming data on Port 1 and Port 2.
TCP	Indicates active TCP connection on Port 2.
PORT 1	USB standard B type connector. This port is referenced as 'Port 1'. Use the USB for initial setup of the encoder or for its local control. The encoder operates also with no cable connected.

3.2 Rear Panel



12V DC	Power supply connector. See section 4.3 for details.
Ethernet Defaults	Resets the Ethernet parameters to defaults. Press and hold for at least 3 seconds. Then recycle the encoder's power. See section 6.3.5 for details. Use a paper clip or similar thin object.
PORT 2	Ethernet RJ-45 connector. This port is referenced as 'Port 2'. Use a standard F/UTP Cat 5e Ethernet cable for connection to the Ethernet switch, router, laptop or wall-socket. The built-in LEDs indicate Ethernet link and serial data. The encoder operates also with no cable connected.
OUTPUT	RDS signal output. If the Loop/Side switch is set to the LOOP position, the Output is a sum of the RDS signal and the signal fed to the Input BNC connector.
Loop/Side switch	Allows the input signal to be added to the output signal. See section 4.2.2 for details.
INPUT	Optional input for synchronization to the pilot tone or for mixing the RDS signal with existing modulation (MPX) signal.

3.3 Board Layout



3.3.1 Connectors

J2 – 12 V power supply connector (2.1 mm)
Central pin is positive (+)

J3 – Output

J8 – Ethernet socket

J5 – USB socket (standard B type)

J7 – Pilot or MPX input

J12 – Logical control inputs/outputs

- 1: TA output
- 2: Program switch input
- 3: TA/EON1TA switch input
- 4: Ground
- 5: +5V output (max. 50 mA)
- 6: RDS enabled input

J19 – 5 V Output for LCD (optional) backlight

- 1: +5V
- 2: Ground

B1 – Lithium battery 3 V for real time backup. Estimated endurance is 10 years. Replace by CR2032 type.
Note: EEPROM memory which is used for RDS data storage does not require any voltage to hold the data.

J10 – LCD (optional) display output

1	+5V	8	GND
2	GND	9	GND
3	V0	10	GND
4	RS	11	DB4
5	GND	12	DB5
6	E	13	DB6
7	GND	14	DB7

The LCD is HD44780 compatible, 16x2.

3.3.2 Buttons and Adjustable Elements

J1 – MPX loopthrough switch

B2 – Ethernet defaults (hold for >3 seconds)

R54 – LCD contrast trimmer

3.3.3 LED Indicators

D1 – Pilot tone indication / Firmware update

D2 – Operation / Receive data / Error

D9 – TA (blinking) / RDS2

D10 – TCP connected


4 Installation and Setting-up

4.1 Connection


Basic rules:

- The RDS signal must be fed into modulation input (added to MPX signal if stereo encoder is used).
- If stereo encoder is used, one of its outputs (MPX or pilot tone) should be fed into the RDS encoder input to meet the synchronization requirement.


Following figures show various situations and corresponding methods of connection:




Separate audio processor (stereo encoder) - default connection.




Audio processor with only one MPX output provided.



FM transmitter with only one MPX input provided.



Both the audio processor and the FM transmitter have only one MPX connector provided - loophrough mode. It is preferred not to use this mode if another kind of connection is applicable.



FM transmitter with integrated audio processor.

In case of **mono** transmission (no stereo encoder used) the RDS encoder input may be left unconnected (since there is no need of external synchronization) or it may be used for the audio signal injection in the case that the FM transmitter has only one input connector.

4.2 Controls on the Board

4.2.1 Adjustable elements

Due to completely DSP-based solution there's no adjustable element on the board affecting the RDS or MPX signal.

4.2.2 J1 - MPX loophrough switch

Set the switch to LOOP position only if you want to pass the input signal to the output of the RDS encoder (loophrough mode). **In all other cases the switch must be set to the SIDE position!**

4.3 Power Supply



The RDS encoder can be powered from any power supply, which delivers a stabilized voltage of 12 V DC and a current of at least 300 mA and no more than 2 A. The RDS encoder has built-in fuse and polarity protection. The central conductor of the power supply connector is positive (+).

*Note: After first power-up the RDS encoder will start to generate the RDS signal with factory default values (PS: * RDS *, PI: FFFF, output level 2 Vpp). There is no need to configure anything to turn on the RDS subcarrier.*

4.4 Windows Control Software - First Steps

It is easiest to configure the RDS encoder via USB (Port 1) before first use. For remote connection setup, please follow section 6.3.

1. Install the Windows control software called 'Magic RDS 4', run the setup exe file and go through the simple installation wizard.
2. In the case of USB connection install the USB driver now.
TIP: Some operating systems already come with the USB driver included.
3. Make sure the RDS encoder is connected and powered, all connectors are seated completely.
4. Run the Magic RDS software using Windows Start button.
5. Double-click on the 'Add new connection' icon.
6. Select your device model (P164). Choose the Serial/USB connection and select the COM port the RDS encoder is connected to.
Note: You may find/change the assigned COM port number in Windows Control Panels - System - (Hardware) - Device Manager.
7. Finally click on the Add button. You should see "Connected" or "Opened" in the Recent Events box. Now you are ready. The settings are saved automatically.
8. Configure the basic RDS settings.
Especially check the pages **RDS Content - Program** and **Device Setup - Analog Control**.
Ethernet configuration is accessible in **Device Setup - LAN Settings** (see section 6.3 for details).
9. To change the setting, click on the Test button first. Then, to make that setting permanent, click on the Apply button.
10. The Recent Events box and status bar at the bottom of the window show whether the data was sent successfully. If an error is shown, check the connection to the RDS encoder, its power supply and whether a correct COM port is selected in the connection setup.
11. Follow the Magic RDS help for further details, tools and configuration options.



Note: Latest USB drivers are available at <https://ftdichip.com/drivers/vcp-drivers/>

Note: The P164 is a dynamic RDS encoder, thus it contains two types of memory. These are marked as RAM and EEPROM. Like any other computing system the RAM holds all operational data which are also used for transmission whilst the EEPROM is used for the data storage during power-off. By default the button Test or External text sources fill the RAM only. The Apply or Store button saves the data into EEPROM. If the user forgets to store the data into EEPROM, that settings will be lost when the power is disconnected.

4.5 Level and Phase Adjustment

4.5.1 RDS signal output level



Important note: There is no universal setting for the RDS level. Due to various input sensitivity of different FM broadcast equipment it is absolutely necessary to check and adjust the RDS level during the installation!

The correct level should be between 2 and 11 % of the audio multiplex signal, measured by oscilloscope in peak-to-peak values on the modulator input. Recommended value is such that results in 3 kHz deviation of the FM carrier. Don't forget that the maximum total FM carrier deviation with RDS and MPX signal is 75 kHz. It is much easier to use any FM broadcast analyzer for setting the RDS level precisely.

Adjusting higher RDS level results in better RDS reception in areas covered with weak signal. This is especially important if using scrolling PS or sending a lot of text information or graphics. However consider following aspects before adjusting higher RDS level:

- the MPX (audio) level must be decreased a little to meet the overall FM deviation limit,
- automatic tuning using alternative frequencies (AF) will appear slower – the receiver will rate the signal reception as good although there may be a subjective reason for tuning to another frequency.

Allowed deviation range of the FM carrier caused by **RDS/RBDS** is **1.0 to 7.5 kHz**.
The overall peak frequency deviation shall not exceed **75 kHz**.

Example

Typical sensitivity of the transmitter's composite (MPX) input is 3.5 volts peak-to-peak for 100 percent deviation. In such a case, the recommended RDS signal level is approximately $3500 \times 3.0 / 75 = 140 \text{ mVpp}$.

If using SCA input on the transmitter, take into account that there may be a fixed or variable signal attenuation on this input so the RDS signal level needs to be increased adequately, up to +20 dB (10 times higher) than calculated.

4.5.1 Adjusting the RDS output level

The RDS level can be adjusted after establishing a connection to the encoder, using one of these two methods:

In the Windows software

The control is available in section Device Setup, page Analog Control.

Enter the RDS level directly in mVpp unit and click on the Test button. Or check the 'Track' box and adjust the level as desired. Finally confirm by the Apply button.

In terminal, using ASCII command **LEVEL=**

The P164 RDS encoder allows direct adjusting of the RDS level in 256 steps, in range 0 to 255, by assigning a corresponding value to the LEVEL parameter. Each step represents approx. 15.6 mV increase.

Desired step count can be calculated as

$$LEVEL = \left(256 \times \frac{\text{Output RDS level}}{4000} \right) - 1$$

Actual output RDS level (in **mV p-p**) can be calculated as

$$\text{Output RDS level} = \frac{LEVEL + 1}{256} \times 4000$$

4.5.2 RDS2 signal output level

The RDS level adjustment is valid for both the RDS and RDS2 subcarrier configurations.

In the RDS2 configuration, the output level value is a sum of two subcarriers, 57 kHz and 66.5 kHz. Amplitude ratio between these subcarriers is 10:11. The subcarriers are phase-aligned to achieve optimal overall FM deviation.

When enabling the RDS2, signal level of stream 0 (57 kHz) drops to approx. a half of the original (RDS) level and may require to be re-adjusted according to the broadcaster needs.

No special equipment is needed for the RDS2 signal level adjustment. For instance, if conventional FM analyzer shows 2.7 kHz FM deviation for the RDS, the upper subcarrier now has 3.0 kHz. Various experiments have shown that this is near the optimal value, for seamless RDS2 file reception at majority of the covered area.

4.5.3 Phase adjustment for stereo broadcast


The phase adjustment between RDS subcarrier 57 kHz and pilot tone is an optional procedure applicable for stereo broadcast (for mono there's nothing to adjust). The adjustment is made using the Windows control software or using the `PHASE=` command. Make sure the external synchronization is enabled (check the command `EXTSYNC` or the item 'Subcarrier reference source' on the Analog Control card in the Windows control software, it must be set to Auto).

From factory the phase shift is already adjusted so user may skip this chapter.

1. Fetch pilot or MPX signal to the RDS encoder. The PILOT LED will indicate that the pilot tone is present.
2. Adjust correct phase shift (0 or 90 degrees phase shift between 19 kHz pilot tone and 57 kHz RDS subcarrier, measured on transmitter input, see the oscillograms). The phase adjustment would be difficult without an oscilloscope or specialized measuring instrument.

Note: The phase adjustment is only optional. In all cases make sure the pilot tone is indicated on the RDS encoder by the PILOT LED.

Oscillograms



Measuring conditions: Two-channel analogue oscilloscope, CH1: pilot (or MPX without audio), CH2: RDS output, trigger source: CH1, vertical function: CH1+CH2, horizontal: 5 μ s/div.

4.6 Setting Basic RDS Data

Before getting on-air with the RDS signal, you will need to decide on the settings to be used. The following RDS services must be set as the first. Use the Windows control software and its GUI. For more experienced users or those without a Windows PC, any terminal programme can be used (see chapter 6.5).

Note: When attempting to set-up a unit that was already placed in operation before, the user should clear the encoder first. In the Windows control software, go to Device Setup – Special – Initialize.

4.6.1 PI (Program Identification)

This is very important information that enables the receiver to distinguish between countries, areas in which the same program is transmitted, and the identification of the program itself. The code is not intended for direct display and is assigned to each individual radio program, to enable it to be distinguished from all other programs. The PI code consists of four characters (hexadecimal numbers).

The first character identifies country:

0	Cannot be assigned.	8	CR, SR, GA, GM, NE, SC, PS, BG, NL, PT, IR, PH, CN
1	AI, BO, GT, CM, NA, SL, DE, GR, MA, ME, MD, KI, KW, LA	9	CU, PA, UY, GN, BI, TD, AL, DK, LI, LV, SI, SA, NZ, JP, PG
2	AG, CO, HN, CF, LR, ZW, DZ, CY, CZ, IE, EE, BT, QA, TH	A	AR, DM, KN, ZA, AC, GW, MU, AT, GI, IS, LB, AM, AF, SB, SG
3	EC, JM, AW, DJ, GH, MZ, EH, AD, SM, PL, TR, KG, BD, KH, TO	B	BR, DO, LC, MX, BF, BW, CD, HU, IQ, MC, AZ, UZ, MM, BN, MV, YE
4	FK, MQ, MG, MR, UG, AO, IL, CH, VA, MK, PK, WS	C	BM, CL, SV, VC, CG, KM, CI, SD, MT, GB, LT, HR, GE, CN, LK, ID
5	BB, GE, MS, ML, ST, SZ, RW, IT, JO, SK, TJ, FJ, IN	D	AN, GD, HT, MX, TG, TZ, DE, LY, RS, KZ, KP, TW, AE
6	BZ, PY, TT, AO, CV, KE, LS, BE, FI, SY, UA, OM, MO	E	GP, TC, VE, MX, BJ, ET, ZM, ES, RO, SE, TM, BH, KR, NP, FM
7	KY, NI, PE, GQ, SN, SO, RU, LU, TN, KS, NR, VN	F	GL, BS, GY, VG, PM, NW, NG, ER, EG, FR, NO, BY, BA, MY, HK, VU, MN

Note: AU, CA and US are not included in the table above due to specific rules in the PI assign.

The second character identifies program type in terms of area coverage:

0	Local	Local program transmitted via a single transmitter only during the whole transmitting time.
1	International	The same program is also transmitted in other countries.
2	National	The same program is transmitted throughout the country.
3	Supra-regional	The same program is transmitted throughout a large part of the country.
4 to F	Regional	The program is available only in one location or region over one or more frequencies, and there exists no definition of its frontiers.

The third and fourth characters are used to clearly identify different stations within the area of coverage.

Important note: Meaning of some PI digits may be different for US RBDS.

Important note: If the station has only one transmitter, second PI digit must be zero (x0xx).

Important note: Factory default PI value is FFFF and it's needed to change it as soon as possible to avoid the situation that two different stations with common area of coverage have the same PI. For each station in the same location the unique PI must be assigned. Stations that carry different program must be unambiguously identified by the last two PI digits. In other case they are recognized as one station by car radios, regardless of any other service settings. If the broadcaster hasn't received the 4-digit PI from authority, he must choose such number that is not in conflict with other stations in the location.

4.6.2 PS (Program Service name)

The PS name is max. 8 character long radio station name that will be shown most of the time on the radio display. Advanced use of the PS (Dynamic/Scrolling PS) is discussed later.

4.6.3 PTY (Program Type)

The PTY code defines the type of the programme broadcast within 31 possibilities. See chapter 7.2 for a complete list. This code could be used for search tuning.

Important note: PTY number 1 (News) should never be left on all the time. Use PTY number 3 (Info) for this purpose.

4.6.4 TP (Traffic Program)

This is a flag to indicate that the tuned program carries traffic announcements. The TP flag should only be set on programs which dynamically switch on the TA identification during traffic announcements. The flag shall be taken into account during automatic search tuning.

4.6.5 MS (Music/Speech)

This is a two-state signal to provide information on whether music or speech is being broadcast. The signal would permit receivers to be equipped with two separate volume controls, one for music and one for speech, so that the listener could adjust the balance between them to suit his individual listening habits.

4.6.6 AF (Alternative Frequencies)

The Alternative Frequencies are used to tell receivers what frequencies they can receive the radio station on. This facility is particularly useful in the case of car and portable radios. For this to work, each transmitter must have RDS with the same PI code.

Important note: If second PI digit is set to zero (x0xx), this indicates that the station has only one transmitter and the AF list is ignored on most receivers.

For complete RDS service description visit the website, section Support.


5 RDS Services and Features

5.1 Broadcast Automation System Link-up

To send dynamic data via the RDS it's very useful to link the RDS encoder with your broadcast automation system. This results in a possibility of sending commercials, current song information, program announcements and other kind of information. All broadcast systems can be linked with the P164. The link may be either indirect or direct.

5.1.1 Indirect Link

In this configuration, the broadcast automation system does not communicate directly in the RDS encoder's language but rather it updates the text information in a specific file on the disk. That file is periodically read and processed by the RDS encoder's control software.




Default Windows control software for the P164 RDS encoder is the **Magic RDS 4**. This application including documentation, tutorials and examples of use can be downloaded from the Website, at the product page. The text processing is accessible through menu item Tools - External text sources.

Since probably hundreds of automation systems are used around the world and new versions are released often, information in this manual cannot be full-scale. For information about how to configure the broadcast automation system text output please follow its documentation or contact the software vendor.

5.1.2 Direct Link

In this configuration, the broadcast automation system drives the RDS encoder directly via its communication port, either physical or virtual.



Since some situations require more communications ports or there may be a need to address more RDS encoders in larger networks, the P164 RDS Encoder's control software provides a unique port multiplication features, called Bridges and Virtual Ports. In such case the broadcast automation system connects to the Windows control software.

Virtual Port connection setup procedure

1. In the Magic RDS 4, click on the Virtual Ports icon and then on Add Virtual Port button.
In case of driving more RDS encoders, create a new Bridge first (Add new connection - kind: Bridge, type: Internal Feed).
2. Configure the connection parameters of the Virtual Port so that the broadcast automation system can connect to it.
3. Configure the broadcast automation system, according to step 2.

For detailed information about how to control the RDS encoder contact your broadcast software vendor.

Data format for text services

The P164 RDS encoder supports several formats (protocols) for input data and it's designed to be compatible with all broadcast automation software.

The support includes:

- ASCII commands
- UECP protocol (format given by UECP specification)
- X-Command (described later in this chapter)

Basic data format for ASCII command is as follows:

Prefix (ASCII command): RT1=
Terminating character↵ : <CR> (Carriage return). <CR><LF> accepted as well.

Example:

```
RT1=Now Playing: Julia Michaels - Issues↵
```

See section 7 for complete list of all ASCII commands.

Compatibility commands

To reach the best possible compatibility with broadcast automation systems, the P164 includes a special set of compatibility commands. In the systems where the P164 is not directly supported (or the system is older version) the user may try to select another RDS encoder model to send text messages. Where possible, set the communication as unidirectional.

Command	Translated to
TEXT=	RT1=
DPS=	DPS1=
PS_SCROLL=	DPS1ENQ=

Radiotext Plus (RT+ tagging)

The RT+ feature is designed to let the listener take additional benefit from the Radiotext service by enabling receivers to offer direct access to specific elements of Radiotext. Typically the RT+ feature supports song artist and song title elements. These elements anyway carried in the Radiotext, are identified by their class type, length and location within the Radiotext. The receiver must be equipped with the RT+ function (also called "tagging") to take advantage of this feature.

The RDS encoder includes full support for the RT+ and its handling is highly automated. For direct use your broadcast automation system must support X-Command or the RT+ function either by means of ODA user defined groups or by the command RTP= (see section 7.8 for more details). In other cases the Windows control software used in the indirect link configuration can provide the RT+ service.

X-Command for RDS encoders

The X-Command is the newest and preferred method how to forward text information (incl. tagging) from the broadcast automation system to the RDS encoder. It is based on simplified markup language. The X-Command is fully supported by the P164 RDS Encoder.

Example:

```
XCMD=<rds><item><dest>3</dest><text>Now Playing: <artist>Julia Michaels</artist> -  
<title>Issues</title></text></item></rds>↵
```

For more details follow the information in the document 'X-Command for RDS Encoders'.

5.2 Dynamic PS

Standard RDS enabled receiver disposes of 8-character LCD display but we usually need to show pile of information and commercials. So small display on the one hand and so much demands on the other hand. The P164 solves it by unique system of text messages showing. Although Radiotext service is defined in the RDS standard, this service is not present some receivers (especially older car radios) and has some other limitations. According to the broadcasters needs, the PS service - one of the basic RDS services supported by all receivers - can be usually used to give sequential information. This has become known as 'Dynamic PS' or 'Scrolling PS'.


Note: Using the dynamic PS is restricted in some countries and it's fully prohibited by the RDS standard! The manufacturer is not responsible for incompetent use of this feature. Some receivers may not display the dynamic PS properly for reasons that lie entirely on their side. Never provide traffic information inside the Dynamic PS text!

The P164 RDS encoder offers advanced implementation of the Dynamic PS service. Basic text message length is up to 255 characters (mode independent). Two varieties of the Dynamic PS are present: Dynamic PS 1 (DPS1) and Dynamic PS 2 (DPS2). Both varieties are configurable independently from each other.

Basic configurable parameters are:

- Text content/text source
- Display mode
- Label period or scrolling speed
- Number of transmissions


Example of full dynamic PS use:



The number of transmissions is specified for each Dynamic PS text. The Static PS period (delay between text loops) specifies the time between two repeats of the Dynamic PS text loops. Default PS is displayed during this time.

Four display modes are provided. The mode is switchable 'on the fly', without need to re-enter the text message.

- Mode 0 - Scrolling by 8 characters
- Mode 1 - Scrolling by 1 character
- Mode 2 - Word parsing (see also SETFEAT command for further options)
- Mode 3 - Scrolling by 1 character, text separated by spaces at begin and end



Additional differences exist between Dynamic PS 1 and Dynamic PS 2 (see sections 7.2 and 7.10). In general the DPS1 should be used if on-line connection is available between your studio and the RDS encoder while the DPS2 should be used if the RDS encoder is placed on a site without on-line connection, providing a set of fixed messages.

5.3 Alternative Frequencies


The list of alternative frequencies gives information on the various transmitters broadcasting the same program in the same or adjacent reception areas. It allows switching to another frequency of the same station when leaving the current frequency coverage. This facility is particularly useful in the case of car and portable radios.

Important note: If second PI digit is set to zero (x0xx), this indicates that the station has only one transmitter and the AF list is ignored on most receivers.

Ideally the AF list should only comprise frequencies of neighboring transmitters or repeaters. Entire AF set should be as tiny as possible to allow the receiver to find the strongest frequency quickly. This will improve the listener's experience. Thus there should be more RDS encoders using individual AF sets within larger networks.

Two methods of AF transmitting are possible:

- AF method A is used for stations carrying the same program on all their transmitters. The list may contain up to 25 frequencies.
- AF method B is used for larger lists or when splitting areas or different programs are broadcast.



5.3.1 Method A

This is a default method recommended for most of stations.

To establish a common list of AF-A using a terminal:

Note: Requires only one RDS encoder for entire network (common STL or one main transmitter and two repeaters). The list must contain all frequencies on which the signal from the RDS encoder is carried.

AF=94.3, 95.8, 91.2	Enter the list
*AF	Store the list

To establish a separate list of AF-A for each transmitter:

Note: Requires separate RDS encoder for each transmitter.

Note: All RDS encoders must be using the same PI (Program Identification).

91.2 MHz:

AF=94.3	Enter the list
*AF	Store the list

94.3 MHz:

AF=95.8, 91.2	Enter the list
*AF	Store the list

95.8 MHz:

AF=94.3	Enter the list
*AF	Store the list

5.3.2 Method B

Total capacity: up to 8 lists, up to 12 AF pairs each

Method B AF coding is a more complex method that is used where the number of AFs used by a transmitter and its associated repeater stations exceed 25, or where it is required to indicate frequencies which belong to different regions which at times carry different programs.

More than one transmitter or associated repeaters of the station broadcast the same set of different AF lists in sequence. Total number of AF lists used within entire network is in general identical to the number of transmitters and repeater stations in the network so as to provide a unique list for each transmitting station. In this method the alternative frequencies are individually addressed by transmitting the tuning frequency paired with one alternative frequency. Each list starts with the tuning frequency for which the list is valid, e.g. 94 . 3. All remaining pairs (up to 12) give the tuning frequency together with a valid AF.

For the transmission of the frequency pairs within one block the following convention is used. They are generally transmitted in ascending order ($F1 < F2$), e.g. 94 . 3, 95 . 8 or 91 . 2, 94 . 3. In special cases they are transmitted in descending order, if they belong to different regions, or carry from time to time different programs. If you use the Windows control software, this assures right order automatically.

To establish a common set of AF-B lists using a terminal:

Note: For illustration purpose only. If the network contains only a few frequencies like in this example, the method A is more effective.

AF=A	Switch to method A to allow editing of the AF lists
AF=94 . 3, 94 . 3, 95 . 8, 91 . 2, 94 . 3	Enter the first list for 94.3 MHz
*AF=1	Store the list
AF=95 . 8, 94 . 3, 95 . 8	Enter the second list for 95.8 MHz
*AF=2	Store the list
AF=91 . 2, 91 . 2, 94 . 3	Enter the third list for 91.2 MHz
*AF=3	Store the list
AF=	Terminate the set of AF lists
*AF=4	Store the termination
AF=B	Switch back to method B - start cycling through the lists
*AF	Store the method setting

To read the set of AF-B lists:

AF	Read the AF method being used (A/B)
AF=A	Switch to method A to allow reading of the AF lists
AF=1	Load the first list
AF	Read the list
AF=2	Load the second list
AF	Read the list
AF=3	Load the third list
AF	Read the list
AF=4	Load the fourth list
AF	Read the list, no AF here, terminating
AF=B	Switch back to method B

Notes:

If the number of AFs of a station is larger than 12, the list must be split into two or more lists. These lists are transmitted directly one after the other.

Broadcasters using splitting of a network during certain hours of the day should use AF method B, and not AF method A. The lists should be static, i.e. the AFs included in the list, carrying a different program during certain hours of the day, shall be signaled by transmitting in the descending order ($F1 > F2$). Their PI shall differ in the second digit of the code (using regional variant 4 to F) and may also be static. Switching the second digit of the PI to 1, 2 or 3 informs the receiver that now even AFs transmitted in descending order carry the same program and the receiver may use them for switching.

5.4 Enhanced Other Networks Information (EON) Setup

The EON feature is used to update the information stored in a receiver about program services other than the one received. Alternative frequencies, the PS name, Traffic Program and Traffic Announcement identification as well as Program Type and Program Item Number information can be transmitted for each other service. The relation to the corresponding program is established by means of the relevant Program Identification (PI).

The EON is especially useful for linking two or more stations of the same owner. Most of EON featured receivers gives priority to stations linked by EON when seek function is activated. Since the P164 can store four EON links, up to 5 stations can be linked together.

Station that doesn't carry traffic announcements can refer to a station that does. This situation is described below. For more information see appropriate section in the List of Commands or in the Magic RDS control software help.

5.4.1 Traffic Program and Traffic Announcement codes

The coding to be used is as follows:

Traffic Program (TP)	Traffic Announcement (TA)	Applications
0	0	This program does not carry traffic announcements nor does it refer, via EON, to a program that does.
0	1	This program carries EON information about another program that gives traffic information.
1	0	This program carries traffic announcements but none are being broadcast at present and may also carry EON information about other traffic announcements.
1	1	A traffic announcement is being broadcast on this program at present.

Station which uses the code TP=0, TA=1 must refer to at least one program service which carries traffic information, and has the flag TP=1. When a particular program service begins a traffic announcement, the station that cross-references this service via the EON feature will broadcast a switch signal by setting the appropriate EON TA flag to 1. The EON TA flags can be controlled by software for all four EON links in the P164. The first EON link TA flag can be also controlled by TA/EON1TA input on the board.

The situation described is illustrated on the example below:

5.4.2 Example

Kiss FM is a small station that doesn't carry traffic announcements but refers via EON to City Radio, which is regional station of the same owner that carries the traffic announcements. If the Kiss FM listener has activated the EON feature on his receiver, he will be automatically tuned to City Radio for the duration of traffic announcements.

Station 1: Kiss FM

PI=20F1
PS=KISS FM
TP=0, TA=1
Frequency: 90.2 MHz

Station 1 EON Data:

EON1PI=2501
EON1PS=CITY
EON1TA=(controlled by input on the board)
EON1AF=93.7

Station 2: City Radio

PI=2501
PS=CITY
TP=1, TA=(controlled by input on the board)
Frequencies: 93.7 and 106.2 MHz
(only 93.7 can be received in the area covered by Kiss FM)

Both TA/EON1TA inputs can be wired together and controlled by only one switch or device if the transmitters of 90.2 and 93.7 MHz are placed on the same site.

5.5 Weekly Scheduling


This feature allows scheduling of text messages, program type names, RDS encoder settings and any other commands in hourly, daily and weekly program. The scheduling is provided directly by the P164 unit. Once set, it works with no more support from PC or control application. This is especially useful when the RDS encoder is operating on a site without online connection. In all other cases consider the Magic RDS 4 Task Scheduler feature.

5.5.1 Key features

- The scheduling feature is fully implemented in the P164 unit and works independently
- Almost any RDS service or control command can be scheduled
- Up to 48 scheduling items
- Each item may contain any combination of days in week, up to 12 times (a wildcard is supported on the hour place), program type (PTY) information and any from more than 60 commands

5.5.2 First steps

Let's say that our radio station called 'PRO 88' broadcasts news from Monday to Friday at midday. The news duration is 40 minutes. During the news the PS is set to 'HOT NEWS' and the PTY is set to 1 (News). In common program the PTY is set to 3 (Info).



Scheduling item 01:

Days: 12345 (Monday, Tuesday, Wednesday, Thursday, Friday)
 Times: 12:00
 PTY: 1 (News)
 Command: PS=HOT NEWS

Scheduling item 02:

Days: 12345 (Monday, Tuesday, Wednesday, Thursday, Friday)
 Times: 12:40
 PTY: 3 (Info)
 Command: PS=PRO 88

5.5.3 Text messages scheduling

Although it's possible to change directly the Dynamic PS and Radiotext (using an appropriate command, for example `RT2=The best music in the city`), the maximum text length is limited since maximum command length in each Scheduling item is 35 characters. For longer texts you may use indirect method based on the bank of Messages:

1. Store the text as a Message, for example Message 01.
2. In the Scheduling call the message number, for example `RT2MSG=1` or `DPS2MSG=1` or `XCMD=<rds><msg>1</msg></rds>`.

The Windows control application provides easy GUI for this case.

5.5.4 Troubleshooting

If the scheduling doesn't work as expected, check the following points:



- Scheduling enabled?
- Date and Time actual?
- Commands typed right?

5.6 RDS2 Subcarrier Configuration and Station Logo

5.6.1 Enabling the additional RDS2 data-stream

The subcarrier configuration is controlled by ASCII command `RDSGEN=` (see section 7). In the Window control software, the RDS2 subcarrier configuration can be enabled in Device Setup – Analog Control – RDS Generator.

Two options are available, keeping balance between costs, occupied bandwidth, achievable modulation levels, transfer rate and reliability of data reception under various conditions.



When the RDS2 is enabled, an additional stream 1 will appear in the MPX spectrum at 66.5 kHz subcarrier. Content of the basic stream 0 at 57 kHz subcarrier remains unchanged, providing all original RDS features and full backward compatibility.

*Please keep on mind: Current receivers may not fully support the RDS2.
In some countries, enabling the RDS2 may violate with broadcast license specifications!*

5.6.2 RDS2 Modes of Operation

The RDS2 mode of operation is controlled by ASCII command `RDS2MOD=` (see section 7). In the Window control software, the RDS2 mode of operation can be changed in RDS Content – System – Miscellaneous.

Content of the stream 1 can be controlled partially or fully by an external application, which provide the data coded into the RDS2 group format. All modes of operation allow external applications to send the RDS2 content using the ASCII command `G=`. The mode of operation effectively determines a default (idle state) content of stream 1:

Mode	Designation	Description
0	Tunneling	The stream 1 is effectively a duplicate of the basic stream 0. This is a default setting.
1	RDS2 Buffer / Station Logo	Internal RDS2 Buffer (see the command <code>STORE</code>) is periodically sent in stream 1.

The modes of operation may be enhanced in future, depending on possible RDS2 expansion.

5.6.3 Setup Procedure for the Station Logo Broadcast

The station logo is encoded according to the latest IEC 62106 standard:

Supported format for the logo image is PNG (preferred) or JPG. Recommended logo file size is about 3 kB.

The image aspect ratio is 1:1 (square) or 4:3. The actual number of pixels is not important because the receiver can resize the station logo by applying its aspect ratio.




Image aspect ratios supported by receivers for the station logo

Various graphic tools can be used for optimizing the logo file according to the IEC 62106 specs. The resolution and number of colors can be reduced, as well as overall image complexity, to achieve smallest file size possible.



Setup for the station logo in the Magic RDS 4. The Magic RDS version must be 4.1.8 or later.



1. In the Magic RDS 4, go to Device Setup – Station Logo.
2. Click on the Load button and select the logo file.
3. Click on the Apply button to store the logo.
The logo is now saved in the RDS encoder's non-volatile memory and ready for cyclic transmission.
4. Enable the RDS2 subcarrier configuration (section 5.6.1). Adjust correct RDS level (section 4.5.2).
5. Set the RDS2 mode to 1 (section 5.6.2).
6. Click on the RDS Spy button to verify the logo reception (View – File Receiver).

6 Communication Ports

6.1 Overview

For configuration and control requirements the RDS encoder is equipped with two communication ports. These ports include individual buffers and work in complete independence, i.e. both ports can be used at one time by different applications.

The port overview is given in following table:

Physical plug	Port reference	Port type	Description and purpose
 USB	Port 1	Physical	This port is dedicated for local connection. It is accessible like any standard serial RS-232 port from the computer, using COMx name, where x is the port number assigned in operating system. Virtual COM Port driver ensures compatibility with older software although the connection is physically realized via USB cable.
 Ethernet	Port 2	Physical	This port is a general purpose remote serial port with support of following Ethernet protocols: TCP Server, TCP Client, UDP. A communication setup must be usually performed prior to use of this port. See section 6.3.5 for default configuration.

All ports are universal so they accept complete set of ASCII commands, a connection from the Windows control software, UECF records (depending on setup) as well as connection from broadcast automation software.

Individual access limitations can be configured for each port using the Port Access Control (PAC).


6.2 USB Connection

For the purpose of initial configuration and local control requirements the RDS encoder is equipped with standard USB interface provided on the front panel. This connector allows direct connection to a PC using USB cable type A-B.

USB driver must be installed prior to start communicating. Latest Windows versions are already supplied with the driver. Virtual COM port feature provides seamless compatibility with broadcast automation software.

After successful installation a new COM port will appear in Windows Control Panels - Device Manager ►

To change the assigned COM port number, double-click on the line and go to Port Settings - Advanced.



6.3 Ethernet Connection

6.3.1 Features

- Single connection (TCP Server, TCP Client or UDP)
- Fail-safe monitor with built-in watchdog for maximum reliability
- Optional switching between main and alternative connection
- Support of auto-negotiation, low power consumption
- Ethernet defaults button on rear panel
- Internal website for Ethernet status


For the purpose of initial setup the device supports four different methods of Ethernet configuration:

- Configuration from the Windows control software
- Simple configuration using ConfigTool (UDP broadcast)
- Ethernet configuration using embedded website
- Configuration from a terminal application

6.3.2 Ethernet configuration from the Windows control software (recommended)

This method uses the Windows control software for the device's Ethernet configuration. A working connection to the encoder must already be established, either via Ethernet or **USB**.

Due to extended set of options available, this method of configuration should always be applied before final installation of the device.



Ethernet configuration step by step:

1. Establish a connection to the RDS encoder, either via Ethernet or USB (see section 4.4).
2. In the Windows control software, select Device Setup and then go to the LAN Settings tab.
3. Configure the fields and finally click on the Apply button.
4. The settings will take effect in 10 seconds. The RDS encoder does **not** require to be restarted.


Following table summarizes the Ethernet configuration parameters for the P164 RDS Encoder:

Use DHCP	<p>Embedded DHCP client allows for automated configuration of the Ethernet parameters like IP address or DNS server.</p> <p>Choose Disabled if you want to enter the parameters manually, for permanent configuration or if there's no DHCP function contained in your network.</p>
Work As: TCP Server/Client	<p>For TCP protocol, the user may specify if the RDS encoder is a server (waiting for a client application connection) or a client (actively connects to the specified RDS data providing app).</p> <p><i>Tip: If host name or IP address needs to be specified in the RDS data providing application, the RDS encoder will be a server (most frequent option).</i></p> <p><i>Hint: If the RDS encoder is configured as TCP <u>server</u>, the Magic RDS or other software must be a TCP <u>client</u>, and vice versa.</i></p> <p>The server side must be visible in the network. In internet that means the server requires public IP address and/or correct port forwarding setting on router (if present). Check the firewall settings!</p>
Port Number	<p>Fill the port number in range 1 to 65535. It must match the port number of the RDS data providing application or the Magic RDS 4 connection setup.</p>
Connect To	<p>This option is available if the encoder is configured as a client. Specifies the remote server the encoder will connect to.</p> <p><i>In UDP bidirectional mode of operation, this parameter is required to be filled for sending response from the encoder (usually fill IP address of the PC).</i></p>
Inactivity Timeout <i>Note 1</i>	<p>Enables an inactivity timeout for TCP mode of operation: If no character or command is received during the 1-minute timeout period, the device disconnects itself due to inactivity and the Port 2 resources are released for establishing a new connection.</p> <p><i>Typically the Inactivity timeout applies if the connection is not closed correctly by the remote application. On the other hand, some older applications may report disconnection if the Inactivity timeout is enabled.</i></p>
Fail-safe Monitor <i>Note 1</i>	<p>Enables the fail-safe monitor: If the encoder does not receive meaningful data during the period specified, current Ethernet session is aborted and the encoder performs selected timeout operation. Whatever happens in the network, the fail-safe monitor guarantees the device accessibility once the network operation resumes. This function also prevents unwanted or unauthorized changes of the Port 2 configuration.</p> <p>The timeout value selection must comply with expected data load - the timeout should always be longer than the longest expected gap in the incoming data.</p> <p><i>This option is not available in all methods of configuration. Once enabled, its later disabling can only be made in the Windows control software or in a terminal.</i></p>
Alternative Configuration	<p>Once enabled, then if the main configuration fails due to data timeout, the encoder switches to the Alternative configuration. Otherwise it stays in the Main configuration.</p> <p>Return from the Alternative configuration back to the Main configuration occurs regardless of whether the data is being received or not, after elapsing the period selected.</p>
Website Port	<p>Specifies the embedded web-server port number.</p> <p>Default port number is 80. Such number may be omitted when typing the URL in web browser.</p>
Password	<p>The password is required in order to enable access to the Ethernet configuration website. Default password is admin.</p>

Note 1: For a long-term TCP mode of operation, it is recommended to enable at least one of these two options.


6.3.3 Simple configuration using ConfigTool (UDP broadcast)

This method uses the ConfigTool desktop application for basic Ethernet configuration and getting its status (for example current IP address). Data are carried by UDP broadcast feature so the process is independent of network configuration and initial state of the device.



Simple configuration step by step:

1. Connect the RDS encoder to your local network.
2. Click on the ConfigTool icon.
3. Click on the Search button and then select your device.
4. Configure the fields in the marked area. Keep the UART speed at 19200. Do not change other settings.
5. In Advanced Options, enable the Inactivity timeout by entering 59999 ms (one minute).
6. Finally, click on the Apply Settings button.
7. The settings will take effect in 10 seconds. The RDS encoder does **not** require to be restarted.
8. If needed, continue by entering the connection parameters to the Windows control software and add the new connection. ► Now you can control the encoder remotely.
9. For final setup, it is recommended to follow the section 6.3.2.




Note: The ConfigTool uses UDP port 1460.

Note: The simple configuration cannot be applied if Fail-safe Monitor was previously enabled in the Windows control software. In such a case the ConfigTool provides current status only.

6.3.4 Ethernet configuration using embedded website

The RDS encoder includes HTTP server and web-based user interface. An internet browser may be directed to the encoder's IP address to bring up the Ethernet configuration website. RDS content cannot be changed this way.



Simple configuration step by step:

1. Type the RDS encoder's IP address to address bar of the web browser. Recommended browser is Mozilla Firefox.
2. Type the password. Default password is **admin**. In some browsers, the Login button must be clicked several times.
3. Click on Basic Settings.
4. Configure the fields in the marked area. Keep the UART speed at 19200. Do not change other settings.
5. Confirm by Save Settings button.
6. In Advanced Options, enable the Inactivity Timeout by entering 59999 ms (one minute).
7. Finally, click on the Reset button. The RDS encoder itself will **not** be restarted.
8. The settings will take effect in 10 seconds.
9. For final setup, it is recommended to follow the section 6.3.2.

Note: The embedded website cannot be used for changing the configuration if Fail-safe Monitor was previously enabled in the Windows control software. In such a case the website provides current status only.

6.3.5 Factory Default Connection Parameters

Following table summarizes factory default parameters.

Use DHCP	No
IP Address	192.168.1.88
Subnet Mask	255.255.255.0
Gateway	192.168.1.1
DNS Server	114.114.114.114
Work As	TCP Server
TCP Port	5000
Inactivity Timeout	Disabled

The default configuration can be recalled any time by pressing the Ethernet defaults button:

1. Make sure the encoder is powered.
2. Press the button for more than 3 seconds. Use a paper clip or similar thin object.



3. Recycle the encoder's power (power-down and power-up).
4. Configure the device as required.

Hint: In the factory default configuration, the encoder is directly accessible in networks which use IP addresses in format 192.168.1.xxx. Connection is instantly possible to IP address 192.168.1.88, port 5000.

6.4 Port Access Control

The Port Access Control (PAC) is primarily a security feature that restricts the RDS encoder control via each port by means of a command code and associated enable/disable flag. The user may specify for each port which RDS services are allowed to be sent, configured and viewed via that port.

The port is identified by its number (1 or 2). The command is identified by its code (see the document 'P132 RDS Encoder – Communication Ports and Internet Functions'). The RDS encoder is set from factory so that all commands are accepted (enabled) on all ports.

The PAC feature applies to both the ASCII commands and the UECP commands on all ports. An exception from this rule exists for USB port: ASCII commands on this port cannot be disabled so local configuration is always possible.

If the UECP commands are completely disabled by ASCII command `UECP=0`, the PAC has no effect on UECP commands.

The Port Access Control feature can be easily configured in the Windows control software (**Device Setup – Communication**) or via ASCII command `PAC`.

Useful notes for the Port Access Control

- Commands executed using internal scheduler, are never restricted by the PAC.
- The PAC does not affect transmission of any service. For example, if Radiotext is being transmitted, disabling the Radiotext command (code AB) does not stop its transmission. Use appropriate commands for that purpose.

6.5 Working with a Terminal Application

This section explains how to make the settings above from a terminal application.

All RDS encoder's settings and configuration incl. text messages etc. can be made from a terminal using a set of ASCII commands. (The Windows GUI based application effectively does the same; it translates the user's data into the ASCII commands.)

1. In the case of USB connection install the USB driver now.
2. Make sure the RDS encoder is connected and powered, and all connectors are seated completely.
3. On the PC, run an application or program emulating or possessing an ASCII terminal. For example the Terminal in the Magic RDS 4 presents all the characteristics to easily communicate in ASCII mode with the RDS encoder.
Note: Latest Windows versions unfortunately no longer contain terminal application. That needs to be installed additionally from public resources. Suitable replacement for the Windows HyperTerminal is the PuTTY client that is available for free download at <http://www.putty.org>.
4. For USB connection configure the communication parameters as follows:

Transmission speed	2400 bps (default, see note)
Data bits	8
Parity	None
Stop bits	1
Flow control	None

Note: If the RDS encoder was previously in use, there may remain any speed from 1200, 2400, 4800, 9600 or 19200 bps. The Magic RDS 4 detects the speed automatically.

5. For TCP connection, fill the encoder's IP address and network port number on which the encoder listens for the connection. The RDS encoder must be configured before using the TCP connection.

Once configured, the terminal can be used. To check if the hardware and logic configuration work as planned, type for example HELP and press <Enter> to display the list of all commands. If no or unknown characters are displayed on the screen, try again a second time, otherwise, check the following points:

- RDS encoder turned on?
- Cable used (does the LED1 indicate incoming characters?)
- Configuration of the terminal application

To display the commands entered at the keyboard on the screen, type the command ECHO=1 followed by <Enter>. If all characters written are displayed twice, type ECHO=0 and press <Enter>.

To store this parameter into a non-volatile EEPROM memory, type *ECHO and press <Enter>.

To display actual parameter value, type ECHO and press <Enter>.

Now you made first steps with the RDS encoder command interpreter.

6.6 Command Interpreter

The RDS encoder command interpreter meets the following rules:

Any instruction sent to the RDS encoder must be **validated** by <Enter>. Before validating you may correct the characters by pressing <Backspace>.

There are several methods of use for the commands:

- Query or command without argument, ex. HELP
Shows the parameter value or performs the operation.
- Command with argument, ex. ECHO=1
Assigns the value to the parameter.
- Memory store command, ex. *ALL
Stores the parameter value(s) into the non-volatile EEPROM memory.
- Memory store command with argument, ex. *MSG01=
Assigns the value to the parameter and stores it immediately into the non-volatile EEPROM memory.


Not all methods are available for all commands, see Command Summary, section 7.1.

Depending on the command processing success, several characters (followed by two pairs of carriage return and line feed characters) can be returned by the RDS encoder:

+	Command processed successfully
!	Unknown command
-	Invalid argument
/	Command processed partially

The command interpreter is not case sensitive for the portion before the '='. The value portion is case sensitive, hexadecimal values, if contain letters, must be typed in upper case.

If you wish to retain change of any parameter value during power off, don't forget to store it into EEPROM memory!





A terminal built in the Magic RDS 4.

6.7 Additional Information

This additional information provides all details required for implementation of the P164 protocol into your application (broadcast automation system, messaging system, TMC data source etc.).

6.7.1 Unidirectional or bidirectional – What is the difference?

The P164 supports both unidirectional and bidirectional communication modes. Nothing is required to be set, the mode of operation results only from the method of communication.

<p>Unidirectional (backward channel from the RDS encoder is not present or the data from this channel is ignored)</p> 	<ul style="list-style-type: none"> ✓ Very simple to implement ✓ Low cost data link × No direct feedback from the unit
<p>Bidirectional (both channels are used)</p> 	<ul style="list-style-type: none"> ✓ Reliable remote control × Backward channel may be hard to realize in some cases × Unsuitable for larger networks

6.7.2 Command synchronization

Unidirectional communication:

If sending more commands in sequence, the execution times must be sometimes taken into consideration; otherwise some commands may be discarded after internal buffer filling:

Command	Execution time
PS=, TPS=, DPSx=	up to 400 ms
G=	up to 200 ms
*ALL	200 ms
*EON, *DPSx, *MSGxx=	50 ms
Other store commands	10 ms
All other commands	0 ms (typ.)

The RX buffer size is 90 bytes for each port. For commands with 0 ms execution time, as well as for command batches whose length is shorter than the RX buffer size, there's no need to pay attention for timing.

The execution times result from the EEPROM write cycle duration or from the requirement of internal synchronization with RDS data group order. Most of commands require no perceptible delay.

TX	P	S	=	P	R	O	_	8	8	←	(execution time)	(next command may follow)
----	---	---	---	---	---	---	---	---	---	---	------------------	---------------------------

Legend:

TX - data sent to the RDS encoder, ← - CR (char. 13, <Enter>)

Bidirectional communication:

Next command can be sent after receiving confirm sequence from previous command. This ensures right timing and optimal channel usage in all cases. There is no need to consider any timing or delays.

TX	P	S	=	P	R	O	␣	8	8	←								(next command may follow)
RX (ECHO=1)		P	S	=	P	R	O	␣	8	8	(exec. time)	←	↓	+	←	↓	←	↓
RX (ECHO=0)											(exec. time)	←	↓	+	←	↓	←	↓

TX	P	S	←															(next command may follow)
RX (ECHO=1)		P	S	←	↓	P	R	O	␣	8	8	←	↓	+	←	↓	←	↓
RX (ECHO=0)				←	↓	P	R	O	␣	8	8	←	↓	+	←	↓	←	↓

TX	*	P	S	←														(next command may follow)
RX (ECHO=1)		*	P	S	(exec. time)	←	↓	+	←	↓	←	↓						
RX (ECHO=0)					(exec. time)	←	↓	+	←	↓	←	↓						

Legend:
 TX - data sent to the RDS encoder, RX - data read from the RDS encoder, ← - CR (char. 13), ↓ - LF (char. 10)

6.7.3 Useful notes

- ASCII char. 9 (TAB) is converted to char. 32 (space).
- The port time-out is 2 minutes. If no character is received during this time, the command line on that port is internally cleared.
- For automated control (machine to machine), if getting a response from the encoder, the block of echoed characters should be entirely ignored. That is, after starting to send the command, the control application should ignore all characters received until the application receives first CR+LF from the encoder. This ensures receiving of correct data regardless of the echo state.

7 List of Commands

7.1 Command Summary

Basic:

AF	AF=	*AF	*AF=	Alternative Frequencies
AFCH	AFCH=	*AFCH		Alternative Frequency Channels
DI	DI=	*DI		Decoder Identification
DPS1	DPS1=	*DPS1		Dynamic PS 1
	DPS1ENQ=			Dynamic PS 1 Enqueue
DPS2	DPS2=	*DPS2		Dynamic PS 2
DPS1EN	DPS1EN=	*DPS1EN		Dynamic PS 1 Enable
DPS2EN	DPS2EN=	*DPS2EN		Dynamic PS 2 Enable
DPS1MOD	DPS1MOD=	*DPS1MOD		Dynamic PS 1 Mode
DPS2MOD	DPS2MOD=	*DPS2MOD		Dynamic PS 2 Mode
DPS1REP	DPS1REP=	*DPS1REP		Dynamic PS 1 Number of Repeating
DPS2REP	DPS2REP=	*DPS2REP		Dynamic PS 2 Number of Repeating
DTTMOUT	DTTMOUT=	*DTTMOUT		Default Text Timeout
EQTEXT1	EQTEXT1=	*EQTEXT1		Equal Text 1
LABPER	LABPER=	*LABPER		Label Period
MS	MS=	*MS		Music/Speech
PI	PI=	*PI		Program Identification
PS	PS=	*PS		Program Service name
PTY	PTY=	*PTY		Program Type number
PTYN	PTYN=	*PTYN		Program Type Name
PTYNEN	PTYNEN=	*PTYNEN		PTYN Enable
RT1	RT1=	*RT1		Radiotext 1
RT1EN	RT1EN=	*RT1EN		RT1 Enable
RT2	RT2=	*RT2		Radiotext 2
RT2EN	RT2EN=	*RT2EN		RT2 Enable
RTPER	RTPER=	*RTPER		Radiotext Switching Period
RTTYPE	RTTYPE=	*RTTYPE		Radiotext Type
RSTDPS	RSTDPS=	*RSTDPS		Restart Dynamic PS
SCRLSPD	SCRLSPD=	*SCRLSPD		Scrolling PS Speed
SPSPER	SPSPER=	*SPSPER		Static PS Period
TA	TA=	*TA		Traffic Announcement
TATMOUT	TATMOUT=	*TATMOUT		TA Timeout
TP	TP=	*TP		Traffic Program
TPS	TPS=	*TPS		Traffic PS
INIT				Initialization
		*ALL		Store All
HELP				Help

EON:

EONxAF	EONxAF=		EON x Frequencies
EONxAFCH	EONxAFCH=		EON x Frequency channels
EONxEN	EONxEN=		EON x Enable
EONxPI	EONxPI=		EON x Program Identification
EONxPS	EONxPS=		EON x Program Service name
EONxPSN	EONxPSN=		EON x Program Service Number
EONxPTY	EONxPTY=		EON x Program Type number
EONxTA	EONxTA=		EON x Traffic Announcement
EONxTP	EONxTP=		EON x Traffic Program
		*EON	Store all EON data into EEPROM

x is in range 1-4

Note: Almost all commands have their equivalent in the Windows control software, accessible through its GUI.

Messages:

MSGxx		*MSGxx=	Text Message
MSGxxD		*MSGxxD=	Message Destination
MSGLIST			List of Messages
DPS2MSG	DPS2MSG=	*DPS2MSG	Dynamic PS 2 Message Number
RT2MSG	RT2MSG=	*RT2MSG	Radiotext 2 Message Number

xx is in decimal range 01-99

Scheduling:

SLIST			List of Scheduling Items
SxxC		*SxxC=	Scheduling Item Command
SxxD		*SxxD=	Scheduling Item Days
SxxP		*SxxP=	Scheduling Item PTY
SxxT		*SxxT=	Scheduling Item Times
SEN	SEN=	*SEN	Scheduling Enable

xx is in decimal range 01-48

System:

COMSPD	COMSPD=	*COMSPD	Port 1 Speed
CT	CT=	*CT	Clock Time and Date
DATE	DATE=		Date
ECHO	ECHO=	*ECHO	Terminal Echo
EXTSYNC	EXTSYNC=	*EXTSYNC	External Pilot Synchronization
LEVEL	LEVEL=	*LEVEL	RDS Signal Level
LTO	LTO=	*LTO	Local Time Offset
MJD	MJD=		Modified Julian Day
PHASE	PHASE=	*PHASE	RDS Signal Phase
PILOT			Pilot Tone Present
PSNMAIN	PSNMAIN=	*PSNMAIN	PSN of Main Program
RDS2MOD	RDS2MOD=	*RDS2MOD	RDS2 Mode of Operation
RDSGEN	RDSGEN=	*RDSGEN	RDS Generator
RESET			Reset
SETFEAT		*SETFEAT=	Special Features
SPEED	SPEED=	*SPEED	Port 1 Speed
STATUS			RDS Encoder Status
TIME	TIME=		Time
VER			Firmware Version

Ethernet configuration:

SETCTM		*SETCTM=	Port 2 Fail-Safe Monitor
SETCTS		*SETCTS=	Port 2 Configuration Loading and Fail-Safe Monitor
SETLAN		*SETLAN=	LAN Setup
SETPORT2		*SETPORT2=	Port 2 Main Configuration
SETPORTA		*SETPORTA=	Port 2 Alternative Configuration

Advanced:

ADR		*ADR=	Encoder Address List
CC		*CC=	Conditional Command
	EAS=		Send EAS Text Message
	EASTIME=		Set EAS Timer
ECC	ECC=	*ECC	Extended Country Code
ECCEN	ECCEN=	*ECCEN	ECC and LIC Enable
	G=		Send RDS or RDS2 Group
GRPSEQ	GRPSEQ=	*GRPSEQ	Group Sequence
LIC	LIC=	*LIC	Language Identification Code
PAC y, zz	PAC y, zz=	*PAC	Port Access Control
PROGRAM	PROGRAM=	*PROGRAM	Program Set Selection
PSW			PS Window
Rabbbb, cc			Read Memory
RTP	RTP=		Radiotext Plus Tagging Data
RTPRUN	RTPRUN=		Radiotext Plus Running Bit
	SETSPY=		Set RDS Monitoring Counter
SHORTRT	SHORTRT=	*SHORTRT	Short Radiotext
SITE		*SITE=	Site Address List
		*STORE=	Write to the non-volatile RDS2 Buffer
UDG1	UDG1=	*UDG1	User Defined Groups 1
UDG2	UDG2=	*UDG2	User Defined Groups 2
UECP	UECP=	*UECP	General UECP Enable
	XCMD=		X-Command for RDS encoders

y is in range 0 to 2

zz is in range 00 to FF (hex)

7.2 Basic Commands

AF	Alternative Frequencies	(87.6-107.9), A, B, (1-8)
Current list of alternative frequencies in MHz representation in range of 87.6-107.9 MHz. Up to 25 items are allowed in the list.		
In addition this command switches between AF method A and B and allows working with different AF lists for the method B.		
For more details about the method B follow the section 4.6.6. From factory the AF method is set to A.		
AF=103.5, 98.0	Sets the alternative frequencies to 103.5 and 98.0 MHz (method A)	
AF	Shows current AF list. Returns "B" if method B is active.	
*AF	Stores the AF list into EEPROM (default space for method A)	
*AF=1	Stores the AF list into EEPROM (to a space used by method B)	
AF=87.5	Not allowed (87.5 MHz not defined in original RDS standard)	
AF=108.0	Not allowed (108.0 MHz not defined in original RDS standard)	
AFCH	Alternative Frequency Channels	H (01-CC)
Current list of alternative frequency channels in hexadecimal representation in range of 01-CC (87.6-107.9 MHz). Up to 25 items are allowed in the list.		
AFCH=01, 3B	Sets the alternative frequencies to 87.6 and 93.4 MHz	
AFCH=00	Not allowed (87.5 MHz not defined in original RDS standard)	
AFCH=CD	Not allowed (108.0 MHz not defined in original RDS standard)	
DI	Decoder Identification	(0-15)
Identification of the decoder to be used by the receiver.		
DI=1	Standard transmission - stereo.	
DI=0	Standard transmission - automatic stereo/mono set depending on pilot tone presence.	
DPS1	Dynamic PS 1	
Up to 255 characters long text message to be displayed on receiver instead of static PS name. Primarily used for song titles streaming etc.		
DPS1>Hello World	Sets the DPS1 text	
DPS1=	Clears the DPS1	
DPS1EN	Dynamic PS 1 Enable	(0, 1)
Enables (1) or disables (0) the Dynamic PS 1 text.		
DPS1EN=1	Enables the DPS1 text.	
DPS2EN	Dynamic PS 2 Enable	(0, 1)
Enables (1) or disables (0) the Dynamic PS 2 text.		
DPS1ENQ	Dynamic PS 1 Enqueue	
Advanced version of the DPS1 command. Places the text to a one level deep queue. New text will not be displayed on the receiver until old text reaches its end. Applies only to text length <128 characters.		
DPS1ENQ>Hello World	Sets the following DPS1 text	
DPS2	Dynamic PS 2	
Up to 255 characters long text message to be displayed on receiver instead of static PS name. Alternatively used in conjunction with <i>Messages Commands</i> .		
DPS2>Hello World	Sets the DPS2 text	
DPS2=	Clears the DPS2	
DPS1MOD	Dynamic PS 1 Mode	(0-3)
Display mode for the DPS1 text.		
0 - Scrolling by 8 characters		
1 - Scrolling by 1 character		
2 - Word alignment scrolling		
3 - Scrolling by 1 character, text separated by spaces at begin and end		
Note: In mode 3 the maximum text length is limited to 240 characters.		
DPS1MOD=3		

DPS2MOD	Dynamic PS 2 Mode	(0-3)
Display mode for the DPS2 text.		
0 - Scrolling by 8 characters		
1 - Scrolling by 1 character		
2 - Word alignment scrolling		
3 - Scrolling by 1 character, text separated by spaces at begin and end		
<i>Note: In mode 3 the maximum text length is limited to 240 characters.</i>		
DPS2MOD=3		
DPS1REP	Dynamic PS 1 Number of Repeating	(0-127)[CLR]
Specifies number of repeating for the DPS1 text message. Optionally the DPS1 text is then cleared.		
Without the optional CLR parameter specified the command has effect only if DPS2 is enabled.		
Number of repeating = number of transmissions - 1.		
DPS1REP=1		
DPS1REP=2, CLR		
DPS2REP	Dynamic PS 2 Number of Repeating	(0-255)
Specifies number of repeating for the DPS2 text message. Has effect only if DPS1 is enabled or if DPS2MSG value is AUTO.		
Number of repeating = number of transmissions - 1.		
DPS2REP=0		
DTTMOUT	Default Text Timeout	(0-254)
Specifies a timeout in minutes for Radiotext 1. If no RT1 has been received during the period, the RT1 text is replaced by default text. If RT+ service is active, the RT+ running bit is cleared.		
Default text means the RT1 text that is stored in EEPROM memory using *RT1. Following exceptions apply:		
For Program 1, if Message 91 contains a valid X-Command, it is launched on the Default Text timeout event.		
For Program 2, if Message 92 contains a valid X-Command, it is launched on the Default Text timeout event.		
1-254 - Timeout in minutes.		
0 - Function disabled.		
DTTMOUT=10		
EQTEXT1	Equal Text 1	(0, 1)
If set to 1, any update of Radiotext 1 via any port updates also Dynamic PS1 and vice versa. Applies also to UECP control. Has no effect for X-Command.		
EQTEXT1=1		
DPS1=Hello World		
RT1		
LABPER	Label Period	(0-255)
Label Period used in DPS Mode 0 and 2. Increasing the value by 1 increases the period by approx. 0.54 seconds (exact value depends on Group Sequence).		
LABPER=4 Each label is displayed for about 2 seconds.		
MS	Music/Speech	(0, 1)
Music/Speech switch.		
MS=0	Speech program	
MS=1	Music program	
PI	Program Identification	H (1000-FFFF)
Identification code of the radio station. Always contains four hexadecimal digits.		
PI=20FE	OK	
PI=0F55	Not allowed (0 as first digit)	
PS	Program Service name	
Static name of radio station that is displayed on receiver. Max. 8 characters long.		
The PS= command requires additional processing time of up to 400 ms for internal synchronization with RDS group order.		
PS=KISS FM		

PTY	Program Type number	(0-31)
------------	----------------------------	---------------

An identification number to be transmitted with each program item, intended to specify the current Program Type within 31 possibilities.

Program type codes (Europe):

0 - (none)	16 - Weather
1 - News	17 - Finance
2 - Affairs	18 - Children
3 - Info	19 - Social Affairs
4 - Sport	20 - Religion
5 - Education	21 - Phone In
6 - Drama	22 - Travel
7 - Cultures	23 - Leisure
8 - Science	24 - Jazz Music
9 - Varied Speech	25 - Country Music
10 - Pop Music	26 - National Music
11 - Rock Music	27 - Oldies Music
12 - Easy Music	28 - Folk Music
13 - Light Classics Music	29 - Documentary
14 - Serious Classics	30 - Alarm Test
15 - Other Music	31 - Alarm

Program type codes (US RBDS):

0 - (none)	16 - Rhythm and Blues
1 - News	17 - Soft Rhythm and Blues
2 - Information	18 - Foreign Language
3 - Sports	19 - Religious Music
4 - Talk	20 - Religious Talk
5 - Rock	21 - Personality
6 - Classic Rock	22 - Public
7 - Adult Hits	23 - Leisure
8 - Soft Rock	24 - College
9 - Top 40	25 - (unassigned)
10 - Country	26 - (unassigned)
11 - Oldies	27 - (unassigned)
12 - Soft	28 - (unassigned)
13 - Nostalgia	29 - Weather
14 - Jazz	30 - Emergency Test
15 - Classical	31 - Emergency

PTY=10 Sets the Pop Music Program Type (EU)

PTYN	Program Type Name
-------------	--------------------------

Allows further description of the current Program Type, for example, when using the PTY code 4: SPORT, a PTYN of "Football" may be indicated to give more detail about that program.

PTYN=Football

PTYNEN	PTYN Enable	(0, 1)
---------------	--------------------	---------------

Enables (1) or disables (0) the PTYN service.

PTYNEN=1 Enables the PTYN service

RT1	Radiotext 1
------------	--------------------

Up to 64 characters long text message to be displayed on receiver in Radiotext format. Primarily used for song titles streaming, commercials etc.

RT1=Hello World

RT1EN	RT1 Enable	(0, 1)
--------------	-------------------	---------------

Enables (1) or disables (0) the Radiotext 1.

RT1EN=1 Enables the RT1

RT2	Radiotext 2	
Up to 64 characters long text message to be displayed on receiver in Radiotext format. Alternatively used in conjunction with <i>Messages Commands</i> .		
RT2=Hello World		
RT2EN	RT2 Enable	(0, 1)
Enables (1) or disables (0) the Radiotext 2.		
RT2EN=1	Enables the RT2	
RTPER	Radiotext Switching Period	(0-255[:00-59])
Specifies the time in minutes between two switching of the Radiotext. The switching can occur between RT1 and RT2 or between <i>messages</i> specified for RT2 (command RT2MSG=AUTO). Optionally, seconds may be specified as well.		
RTPER=3	Sets the period to 3 minutes	
RTPER=0 : 20	Sets the period to 20 seconds	
RTTYPE	Radiotext Type	(0-3)
Specifies Radiotext type for RT1 and RT2		
0 - A/A. Any Radiotext is always the same type.		
1 - A/B. RT1 is always type A, RT2 is always type B.		
2 - Automatic. Any change/update of the Radiotext causes the A/B flag to toggle. Default option. Required for proper RT+ function.		
3 - Same as 2 but also overrides UECP A/B flag control.		
The meaning of the RT type is: If the receiver detects a change in the A/B flag, then the whole Radiotext display is usually cleared and the newly received Radiotext message segments are written into the display. If the receiver detects no change in the A/B flag, then the received text segments or characters are written into the existing displayed message.		
RTTYPE=2		
RSTDPS	Restart Dynamic PS	(0, 1)
1 - When the Dynamic PS text is changed and no Dynamic PS is running, it will start immediately.		
0 - The SPSPER command drives the Dynamic PS start regardless of the fact that the Dynamic PS text was changed.		
<i>Changing a Dynamic PS text (1 or 2) that is currently running will always cause its restart. This rule does not apply to the DPS1ENQ command.</i>		
RSTDPS=1		
SCRLSPD	Scrolling PS Speed	(0, 1)
Sets high (1) or low (0) speed of scrolling PS transmission. Although setting high speed gives the result looking better, remember that on some receivers or under bad reception conditions the text may be unreadable. The reason is absolutely outside the RDS encoder and comes out from the fact that scrolling PS has never been included in RDS standard. Due to this the high speed is not recommended.		
SCRLSPD=1		
SPSPER	Static PS Period	(0-255)
Specifies the time between two repeats of the Dynamic PS text. Static PS (PS/TPS) is displayed during this time. Increasing the value by 1 increases the period by approx. 2.7 seconds (exact value depends on Group Sequence).		
If value 255 is set, the Dynamic PS will be displayed only once if changed. RSTDPS parameter must be set to 1 in this case.		
<i>If both DPS1 and DPS2 are enabled, the SPSPER cannot be zero (0).</i>		
SPSPER=4	Sets the period duration to about 11 seconds.	

TA	Traffic Announcement	(0, 1)
-----------	-----------------------------	---------------

Indicates instantaneous presence (1) of traffic information during broadcasting.
 When this value is set to 1 by TA input on the board, the value specified by TA command has no effect.
 When this value is set to 1 by TA command, the TA input on the board has no effect.
 Switching the PROGRAM causes clearing of the TA flag.

Note: In some cases the RDS encoder drives the TP and TA flags automatically, especially if EON feature is enabled. This ensures that these flags are set correctly under all conditions.

TA=1

TATMOUT	TA Timeout	(0-127) [+128]
----------------	-------------------	-----------------------

Specifies a maximum duration in minutes during which the TA parameter can remain active.

0 - Disables the TA timeout feature. TA input on the board is level controlled (logic 0 means TA=1).

1-127 - Specifies a maximum duration in minutes during which the TA parameter can remain active (1).
 Then the TA flag is set back to zero (0). TA input on the board is activated by falling edge. Rising edge is ignored.

+128 - Adding 128 results in the same behavior as above except that also rising edge can set the TA back to zero (if detected before the timeout).

Note: The timeout is synchronized with real time clock minutes, i.e. the timeout event can only occur in whole minutes.

Note: The TATMOUT command doesn't affect the EON1TA switching. The input on the board, if used to switch the EON1TA, can be level controlled only.

Note: If TP=0, the TA Timeout is always set to 0.

TATMOUT=0 No timeout. Logic 0 on the TA input results in TA=1, logic 1 or no connection results in TA=0.

TATMOUT=2 TA is activated (set to 1) on falling edge on the TA input (logic 1 to logic 0 transition). After 2 minutes the TA is set back to 0. Rising edge is ignored so may occur anytime.

TATMOUT=130 TA is activated on falling edge on the TA input. The TA is set back to 0 on either the rising edge or after 2 minutes timeout, depending on which event occurs first.

TP	Traffic Program	(0, 1)
-----------	------------------------	---------------

This is a flag to indicate that the tuned program carries traffic announcements. The TP flag must only be set on programs that dynamically switch on the TA identification during traffic announcements. The signal shall be taken into account during automatic search tuning.

Note: In some cases the RDS encoder drives the TP and TA flags automatically, mainly if EON feature is enabled. This ensures that these flags are set correctly under all conditions.

TP=1

TPS	Traffic PS	
------------	-------------------	--

Static text displayed on receiver during traffic announcements. Max. 8 characters long.

The TPS= command requires additional processing time of up to 400 ms for internal synchronisation with RDS group order.

TPS=TRAFFIC

TPS= Disables the Traffic PS

INIT	Initialization
------	----------------

Sets most parameters and services in currently selected Program to their default values. Does not clear *Messages* and *Scheduling* items. Does not clear port and network settings. Apply this command for example if new blank EEPROM is placed on the board or if the RDS encoder was previously used for another station.

INIT	Initialize the program set that is currently selected.
*CC=	Complete initialization procedure.
PROGRAM=6	Replace the HH:MM with actual time and the DD.MM.YY with actual date.
INIT	
*ALL	<i>Note: This initialization sequence must always be applied if new blank EEPROM is placed on the board in production process. Alternatively use the Windows control software: Device Setup - Special - Initialize.</i>
PROGRAM=5	
INIT	
*ALL	
PROGRAM=4	
INIT	
*ALL	
PROGRAM=3	
INIT	
*ALL	
PROGRAM=2	
INIT	
*ALL	
PROGRAM=1	
INIT	
*ALL	
TIME=HH:MM	
DATE=DD.MM.YY	

ALL	Store All
-----	-----------

Stores all settings into the non-volatile EEPROM memory.

*ALL

HELP	Help
------	------

Shows all commands available.

HELP

7.3 EON Commands

EONxAF	EON x Frequencies	(87.6-107.9)
List of Other Network frequencies that can be received in the area covered by linking station. Each item is in MHz representation in range of 87.6-107.9 MHz. Up to 25 items allowed.		
Optional prefix M: can be specified for choosing "mapped AF" method.		
EON1AF=98.0, 99.3		Sets 98.0 and 99.3 MHz frequencies for Other Network 1
EON1AF=M:102.0, 98.0, 88.6, 99.3		Sets the AF using "mapped AF" method.
EONxAFCH	EON x Frequency channels	H (01-CC)
List of Other Network frequency channels that can be received in the area covered by linking station. Each item is in hexadecimal representation in range of 01-CC (87.6-107.9 MHz). Up to 25 items allowed.		
EON1AFCH=01, 3B		Sets 87.6 and 93.4 MHz frequencies for Other Network 1
EONxEN	EON x Enable	(0, 1)
Enables (1) or disables (0) the link to the Other Network.		
EON1EN=1		
EONxPI	EON x Program Identification	H (0000-FFFF)
Identification code of the Other Network. Always contains four hexadecimal digits.		
EON1PI=24F1		
EONxPS	EON x Program Service name	
Program Service name of the Other Network.		
EON1PIN=12, 16, 40		
EONxPSN	EON x Program Service Number	(1-255)
Program Service Number assigned to the Other Network.		
Applies only if the operator requires changing of EON information via UECP.		
EON1PSN=1		
EONxPTY	EON x Program Type number	(0-31)
Program type number of the Other Network.		
EON1PTY=3		
EONxTA	EON x Traffic Announcement	(0, 1)
If set to 1, switches the receiver to corresponding Other Network for duration of the traffic announcement.		
Can't be set to 1 if:		
<ul style="list-style-type: none"> ▪ corresponding Other Network has TP=0 ▪ corresponding Other Network is not enabled 		
The EON1TA flag can be also controlled by TA/EON1TA input on the board.		
Note: Setting any EON TA to is also signaled to the receiver by a series of group type 14B.		
EON1TA=1		
EONxTP	EON x Traffic Program	(0, 1)
Traffic Program flag of the Other Network.		
EON1TP=1		
*EON	Store all EON data into EEPROM	
Stores all EON data into EEPROM. TA flags are not stored.		
*EON		

x is in range 1-4

7.4 Messages Commands

These commands are provided for working with the bank of fixed text messages that is useful especially for offline operation of the RDS encoder or in conjunction with the scheduling feature. Using these commands you may enter the text messages and assign them to Radiotext, Dynamic PS or X-Command.

MSGxx	Text Message	
	Specifies the fixed message text. Since there is a place for 99 messages in the memory, the number xx must be in range 01-99. For Program 1, if Message 91 contains a valid X-Command, it is launched on the Default Text timeout event. For Program 2, if Message 92 contains a valid X-Command, it is launched on the Default Text timeout event. Same rule applies to Program 3 to 6.	
	<code>*MSG01=Hello World</code>	
MSGxxD	Message Destination	(0-3)
	Specifies the destination of the message used for automatic message switching. The number xx must be in range 01-99. 0 - Message not used for automatic switching 1 - DPS2 2 - RT2 3 - DPS2 and RT2 4 - X-Command Timer	
	<code>*MSG01D=1</code>	
MSGLIST	List of Messages	
	Shows all messages present in the memory and its destination. MSGLIST	
DPS2MSG	Dynamic PS 2 Message Number	(0-99, AUTO)
	0 - Default DPS2 text specified by <code>DPS2</code> command or last <code>DPS2MSG</code> command is selected. 1-99 - The message of the number is selected for the DPS2. AUTO - Messages are selected automatically in ascending order. Only messages chosen by the <code>MSGxxD</code> command are selected.	
	<code>DPS2MSG=AUTO</code>	
RT2MSG	Radiotext 2 Message Number	(0-99, AUTO)
	0 - Default RT2 text specified by <code>RT2</code> command or last <code>RT2MSG</code> command is selected. 1-99 - The message of the number is selected for the RT2. AUTO - Messages are selected automatically in ascending order. Only messages chosen by the <code>MSGxxD</code> command are selected.	
	<code>RT2MSG=1</code>	

xx is in decimal range 01-99

7.5 Scheduling Commands

SLIST	List of Scheduling Items	
Shows all scheduling items. Items with no day specified are not showed. Each item is represented by the following order: Item No., Days, Times, Command, PTY.		
SLIST		
SEN	Scheduling Enable	(0, 1)
Enables (1)/disables (0) the scheduling feature.		
SEN=1 Enables the scheduling feature.		
SxxC	Scheduling Item Command	
Specifies the command to execute. Max. command length is 35 characters. Only commands from the second column of the Command Summary are allowed.		
*S01C=RDSGEN=0		
*S03C=RT2MSG=12		
*S04C= Clears (disables) the command for the item 04.		
*S05C=XCMD=<rds><msg>40</msg></rds> Schedules the item 05 to process X-Command stored in Message 40		
SxxD	Scheduling Item Days	(1-7)
Specifies the days for which the item is valid. Monday = 1.		
*S03D=12367		
SxxP	Scheduling Item PTY	(0-31)
Allows including optional Program Type information so that the Command may be used for another RDS service change.		
*S03P=15 Sets the PTY to 15 (Other M)		
*S04P= Clears (disables) the PTY option for the item 04.		
SxxT	Scheduling Item Times	
Specifies the times in 24-hours HH:MM format at which the item command is executed. Wildcard XX can be used instead of hour number meaning that the item will be executed each hour in specified minute. If more items are scheduled for the same time, all these items are executed in ascending order. Up to 12 times allowed for each item.		
*S03T=XX:30,12:00		

xx is in decimal range 01-48

7.6 System Commands

COMSPD	Port 1 Speed	(0-4)
Specifies the port 1 speed (baudrate).		
0 - 1200 bps		
1 - 2400 bps (default)		
2 - 4800 bps		
3 - 9600 bps		
4 - 19200 bps		
This command has the same effect as <i>SPEED</i> but the format of input is different.		
COMSPD=1		
CT	Clock Time and Date	(0, 1)
Enables (1) or disables (0) time and date transmission in CT format.		
CT=1		
DATE	Date	
Specifies current date in DD.MM.YY format.		
DATE=30.11.05 30 th of November 2005		
ECHO	Terminal Echo	(0, 1)
Determines if the RDS encoder sends an echo (1) of each character or not (0), that it receives via the port.		
ECHO=1		
EXTSYNC	External Pilot Synchronization	(0, 1)
0 - Forced internal clock source (for mono transmission)		
1 - Automatic external synchronization if pilot tone is present		
EXTSYNC=1		
LEVEL	RDS Signal Level	(0-255)
Sets the RDS signal level, directly affects the injection of the RDS signal into the FM transmitter.		
0 = minimum level, 255=maximum level. See section 4.5 for details.		
LEVEL=120		
LTO	Local Time Offset	±(0-24)
Specifies the offset between the local time and the universal time (UTC). Expressed in multiples of half-hours.		
LTO=+2		
MJD	Modified Julian Day	H (000000-FFFFFF)
Day, Month and Year coded as Modified Julian Day.		
To find D, M and Y from MJD:		
$Y' = \text{int} [(MJD - 15\,078,2) / 365,25]$		
$M' = \text{int} \{ [MJD - 14\,956,1 - \text{int} (Y' \times 365,25)] / 30,6001 \}$		
$D = MJD - 14\,956 - \text{int} (Y' \times 365,25) - \text{int} (M' \times 30,6001)$		
If $M' = 14$ or $M' = 15$, then $K = 1$; else $K = 0$		
$Y = Y' + K$		
$M = M' - 1 - K \times 12$		
To find MJD from D, M and Y:		
If $M = 1$ or $M = 2$, then $L = 1$; else $L = 0$		
$MJD = 14\,956 + D + \text{int} [(Y - L) \times 365,25] + \text{int} [(M + 1 + L \times 12) \times 30,6001]$		
Y', M', K, L - intermediate variables.		
MJD=00D7CD 18 th of February 2010		
PHASE	RDS Signal Phase	(0-18)
Fixes the relative phase shift between the pilot tone and the RDS signal (57 kHz).		
Changing the value by one results in 9.5 degrees phase shift change.		
The value serves only as a scale, it may not provide a real phase shift value.		
PHASE=8		

PILOT	Pilot Tone Present	
Indicates if pilot tone is present (1) or not (0).		
PILOT		
PSNMAIN	PSN of Main Program	(1-254)
Specifies optional PSN (Program Service Number) for current Program set. This option has effect for UECP control only.		
PSNMAIN=1		
RDS2MOD	RDS2 Mode of Operation	(0, 1)
Controls the RDS generator and subcarrier configuration: 0: Tunneling - The stream 1 is effectively a duplicate of basic stream 0 (default). 1: RDS2 Buffer / Station Logo - The RDS2 Buffer (see command STORE) is periodically sent on stream 1. Other modes are currently undefined and should not be used. In all modes, the G command has higher priority when inserting user-defined RDS2 group to the stream 1.		
RDS2MOD=0		
RDSGEN	RDS Generator	(0-2)
Controls the RDS generator and subcarrier configuration: 0: RDS output disabled - no data goes from the RDS encoder's output. 1: RDS output enabled - single 57 kHz subcarrier (default). 2: RDS2 configuration enabled. Content of the upper subcarrier is given by the RDS2MOD and G commands. <i>Note: Disabling the RDS output has no effect on other functions.</i>		
RDSGEN=1		
RESET	Reset	
Provokes a hardware reset of the RDS encoder and is equivalent to an "off-on" cycle of the RDS encoder.		
RESET		
SETFEAT	Special Features	H (0000-3FFF)
This is a 16-bit Hex value bitmap which holds enabling bits for special RDS encoder features: Bit 0: Dynamic group sequence. If enabled (1), temporarily doubles the 2A group rate after the RT is changed. Bit 1: RT+ group type 11A/13A. Selects group type for RT+ service. Applies to RTP and XCMD commands. Bit 2: reserved, set as 0. Bit 3: X-Command Timer Message - resume (0) or reset (1). Bit 4: Enables scrolling of long words for Dynamic PS Mode 2 (Word parsing mode). Bit 5: Chooses between left alignment (0) and centering (1) for Dynamic PS Mode 2 (Word parsing mode). Bits 6 to 15: reserved, set as 0. <i>Note: The '*' prefix may be omitted for this command.</i>		
SETFEAT=0001 Enables dynamic group sequence, sets group type 11A for RT+		
SETFEAT=0003 Enables dynamic group sequence, sets group type 13A for RT+		
SETFEAT=0000 Factory default value		
SPEED	Port 1 Speed	(1200, 2400, 4800, 9600, 19200)
Specifies the port 1 speed (baudrate). This command has the same effect as COMSPD but the format of input is different.		
SPEED=2400		
STATUS	RDS Encoder Status	
Shows the most important operating values of the RDS encoder. You may also type ??.		
STATUS ??		
TIME	Time	(00:00-23:59, 00:00:00-23:59:59)
Specifies current time in HH:MM format (sets the second counter to 00) or in HH:MM:SS format. The time value specified is a local time valid in the area of coverage.		
TIME=16:40 TIME=09:24:10		

VER	Firmware Version
Returns the firmware version that is currently present in the RDS encoder.	
VER	

7.7 Ethernet Configuration Commands

SETCTM	Port 2 Fail-Safe Monitor
Controls the Ethernet (Port 2) Fail-Safe Monitor. Selects the timeout value and operation. See also section 6.3.2. If the parameter is 0, the Fail-Safe Monitor is disabled and nothing happens. If the parameter is a pair of timeouts, the Fail-Safe Monitor is enabled: First value applies to the Main configuration. The unit is minute * 10. Second timeout value, if greater than 1, applies to the Alternative configuration.	
SETCTM=0	Fail-Safe Monitor disabled.
SETCTM=6, 3	Fail-Safe Monitor enabled. Set the timeout to 60 minutes for the Main configuration and 30 minutes for the Alternative configuration.
SETCTM=6, 1	Fail-Safe Monitor enabled. Set the timeout to 60 minutes for the Main configuration, reset the Ethernet controller if no valid data is received during that time.

SETCTS	Port 2 Configuration Loading and Fail-Safe Monitor
Same as SETCTM but the (Main) Ethernet configuration is applied immediately.	
SETCTS=0	Load the Ethernet module with SETLAN and SETPORT2 settings now. Fail-safe monitor disabled.

SETLAN	LAN Setup
Configures the LAN using a special set of AT commands, excl. port 2 settings. Stores the configuration to non-volatile EEPROM memory. Each value ends by '\$' character. Commands are separated by comma. Maximum length is 255 characters. AT\$ - This command must be always the first. AT+NAME=<device_name>\$ - Device name, which will show in embedded website AT+PASS=<password>\$ - Password required for the embedded website. Cannot contain: '\$' , AT+WEB_PORT=<portnum>\$ - Specifies port number for embedded web-server. Default is 80. AT+IP_MODE=<mode>\$ - Static IP: 0, DHCP: 1 AT+IP=<ip_addr>\$ - IP address AT+MARK=<subnet_mask>\$ - Subnet mask AT+GATEWAY=<gate_addr>\$ - Gate address AT+DNS=<dns_ip_addr>\$ - DNS server IP address	
*SETLAN=AT\$, AT+NAME=P164\$, AT+PASS=admin\$, AT+WEB_PORT=80\$, AT+IP_MODE=0\$, AT+IP=192.168.1.88\$, AT+MARK=255.255.255.0\$, AT+GATEWAY=192.168.1.1\$, AT+DNS=114.114.114.114\$	

SETPORT2	Port 2 Main Configuration
Configures the Port 2 (Main Configuration) using a special set of AT commands. Stores the configuration to non-volatile EEPROM memory. Each value ends by '\$' character. Commands are separated by comma. Maximum length is 127 characters. AT\$ - This command must be always the first. AT+C1_OP=<operating_mode>\$ - TCP server: 0, TCP client: 1, UDP: 2 AT+C1_PORT=<portnum>\$ - local port number AT+C1_CLI_PP1=<portnum>\$ - remote host port number AT+C1_CLI_IP1=<ip_addr>\$ - remote host IP address AT+DNSEN=1\$ - if present, the AT+DOMAIN will apply AT+DOMAIN=<host_name>\$ - remote host domain name AT+C1_IT=<inactivity_timeout_ms>\$ - inactivity timeout for TCP. Disabled: 0, one minute: 59999 (maximum)	
*SETPORT2=AT\$, AT+C1_OP=1\$, AT+C1_PORT=5000\$, AT+C1_CLI_PP1=5000\$, AT+C1_CLI_IP1=192.168.1.99\$, AT+C1_IT=0\$	

SETPORTA	Port 2 Alternative Configuration
Configures the Port 2 (Alternative Configuration). For details, see SETPORT2.	
*SETPORTA=AT\$, AT+C1_OP=1\$, AT+C1_PORT=5000\$, AT+C1_CLI_PP1=5000\$, AT+C1_CLI_IP1=192.168.1.98\$, AT+C1_IT=0\$	

7.8 Advanced Commands

ADR	Encoder Address List	(0-63[,0-63])
-----	----------------------	---------------

Up to two encoder address numbers in range 0 to 63, separated by comma. Applies to UECP control.

*ADR=56

*ADR=12, 35

CC	Conditional Command
----	---------------------

Executes specified command when specified condition occurs. Optional ELSE command supported.

Syntax:

*CC=[aa]bcc:dddddddd

*CC=ELSE:eeeeeeee

where is:

aa - memory address pointer (00-FFF)

b - condition operator

< - lower than

> - greater than

= - equal

! - not equal

B - bit cc of [aa] is set (numbered from LSB to MSB)

cc - value to compare (00-FF) or bit number (00-07)

dddddddd - the command executed if the condition is matched

eeeeeeee - the command executed if the condition is not matched (optional)

Max. command length is 31 characters. Once the command is executed, next execution is stopped until the condition matching changes. In other words, the command is executed only at the condition matching change. Both numbers aa and cc are in hexadecimal representation. Only one CC item is allowed. Only commands from the second column of the Command Summary are allowed.

List of some applicable memory addresses:

13: PTY number (0-31)

15: number of DPS2 characters

28: Message counter (RT2)

29: Message counter (DPS2)

34: number of DPS1 characters

68: timer 0-8A, reset every minute

6A: one of the status bytes (bit 02 - DPS2 is running; bit 03 - DPS1 is running, bit 06 - program input on the board)

71: Dynamic PS counter (points to the character that is currently transmitted on the first PS position)

76: static PS counter (0-SPSPER)

78: DPS number of repeats counter

8B: Group Sequence counter

C6: Scheduling item number waiting (0, 1-48)

CC: timer 0-FF, increased on each end of PS transmission (approx. once per 0.5 sec. by default)

E4: local hour (0-23)

E5: local minute (0-59)

To check visually what value is on each address, type `MEM xx` where xx is the address desired.

***Important note:** The CC is a very "strong" command. Due to a theoretical possibility of bad setting that may cause the unit stop responding (please don't ask for an example) the Conditional Command is not active after power-up for up to 30 seconds. This gives the user a time to type *CC= to disable the Conditional Command before it becomes active.*

*CC=[CC]B03:PS=RADIO	Periodically switches the PS between 'RADIO' and 'PRO 88'.
*CC=ELSE:PS=PRO 88	
*CC=[6A]B06:DPS2MSG=01	If PROGRAM is set to 1 or 2, the program input on the board will select a text Message for the Dynamic PS 2. (If PROGRAM is set to 0, the status bit is always 0.)
*CC=ELSE:DPS2MSG=02	
PTYN=Football	Sets PTYN name to 'Football'. When PTY code 'Sport' is on-air, additional PTYN name is included.
*CC=[13]=04:PTYNEN=1	
*CC=ELSE:PTYNEN=0	
*CC=[4E]B06:RT2EN=1	Enables RT2 for the duration of traffic announcement (TA)
*CC=ELSE:RT2EN=0	
*CC=[E9]!01:COMSPD=1	Does not allow to set port 1 speed other than 2400 bps.
*CC=[E4]>0B:DPS2=Good afternoon	Different DPS2 text for hours in range 0-11 and 12-23. Scheduling feature can be used as well.
*CC=ELSE:DPS2=Good morning	
*CC=[71]<20:DPS1MOD=1	Shows first part of DPS1 in mode 1, then switches to mode 2 for the rest of the text.
*CC=ELSE:DPS1MOD=2	
CC	Shows actual CC settings.
*CC=ELSE:	Disables the ELSE command.
*CC=	Completely disables the Conditional Command feature.

EAS Send EAS Text Message

Activates the EAS (US Emergency Alert System) mode of operation:

Loads the text message to Radiotext 1 and Dynamic PS 1. Sets PTY to 31 (Alert). Sets the EAS timer to 180 seconds.

Other commands changing the Radiotext or Dynamic PS are not accepted during the EAS session.

EAS=Hurricane conditions are expected within your area

EASTIME Set EAS Timer

(0-999)

Number of seconds that the EAS text message should be transmitted. Typically, this command is sent **after** the EAS command. If the timer is set to 0 (or has been decremented to 0), then the RDS encoder will function in its normal mode of operation.

EASTIME=300 Extends the EAS mode duration to 5 minutes.

EASTIME=0 Immediately terminates the EAS mode of operation.

ECC Extended Country Code

H (00-FF)

Uniquely determines the country in conjunction with the first digit of PI.

ECC=00

Unknown/not used/not applicable.

ECC=E2

ECCEEN	ECC and LIC Enable	(0, 1)
Enables (1) or disables (0) the ECC and LIC features.		
ECCEEN=1		

G	Send Group	H (000000000000-FFFFFFFF) or H (0000000000000000-FFFFFFFF)
Orders the RDS encoder to send directly RDS or RDS2 groups whose contents are free. For RDS (stream 0), the Group content is in BBBBCCCCDDDD format where BBBB, CCCC and DDDD represent the contents of the block 2, block 3 and block 4 in hexadecimal expression. The block 1 has not been specified as it is always the PI programmed with the PI command. For more details about the group coding see section 10.2. For RDS2 (stream 1), the Group content is in AAAABBBBCCCCDDDD format where AAAA, BBBB, CCCC and DDDD represent the contents of the block 1, block 2, block 3 and block 4 in hexadecimal expression. The RDS encoder calculates CRC automatically. Using this command, the RDS transmission can then be partially or fully controlled by an external application. For full RDS stream control, 9600 bps or higher com. speed should be used. Next Group can follow after previous command success characters (+). Unlike the UECP control, the G buffer may not contain more than one group for each stream. The buffer is flushed as soon as possible (each stream has a maximum rate of 11.4 groups per second).		
G=380215D1A531	RDS group 3B containing 02 15D1 A531	
G=0000200F20202020	RDS2 group - tunneling a RT segment	

GRPSEQ	Group Sequence
Defines the RDS group sequence. Allows the user to control the group order and adjust repetition rate of individual RDS services. Max. 24 items are allowed. The services and groups are represented by following symbols:	
0	- Four groups 0A (MS, TA, DI, AF, one complete PS)
1	- Group 1A (ECC, LIC)
2	- Group 2A (RT)
A	- Group 10A (PTYN)
E	- Group 14A and 14B (EON)
X	- Group from UDG1
Y	- Group from UDG2
R	- Group 3A/11A (RT+)
U	- One group from the UECP buffer. If the 'U' symbol is not present in the Group Sequence, any possible data groups from the UECP buffer are transmitted as fast as possible, usually making a continuous sequence of groups until the UECP buffer flushes completely. This is a default configuration.
3	- One 3A group from the UECP ODA Configuration buffer (cyclic transmission).
Services, which are not placed in the sequence, are disabled regardless of their individual settings. Services, which are placed in the sequence and are disabled by their individual settings, are ignored (skipped). Inserting a nonsense string will result in the same effect as inserting a single 0. Inserting an unknown symbol will cause ignoring the rest of the string. It's a good practice to assure that at least one 0 is present in each consecutive 6 symbols. It is recommended not to place more than 4 same symbols consecutively. Take into consideration that RDS does not know anything like empty groups or delays between groups. There must be still some groups sent to the output. The GRPSEQ command does not affect: group 4A (CT), user groups inserted using the G command.	
GRPSEQ=02222	Four groups 0A followed by four groups 2A (very high Radiotext transmission rate), other services are disabled.
GRPSEQ=	Sets the groups sequence to default (022E1022EA022XYR3).
GRPSEQ=022E10XXXX	High transmission rate of UDG2. PTYN and RT+ is disabled.
GRPSEQ=X	The RDS content is fully controlled via UDG1 (and possibly the G command).


LIC	Language Identification Code	H (00-FF)
Enables a broadcaster to indicate the spoken language he is currently transmitting.		
LIC=00	Unknown/not applicable	
LIC=09	English	

PAC	Port Access Control
This command is described in the document 'P132 RDS Encoders - Communication Ports and Internet Functions'.	

PROGRAM	Program Set Selection	(0-6)
<p>Selects the program set - copies the program data from EEPROM memory to operational memory. RDS services in selected program set are transmitted by the RDS encoder and can be modified and stored back into EEPROM memory. Six Program Sets are available in the device.</p> <p>1 - Program set 1 is selected (default)</p> <p>...</p> <p>6 - Program set 6 is selected</p> <p>0 - Program input on the board selects the program</p> <p><i>Note: If PROGRAM is set to zero (0), most of store operations are not allowed to protect the data (since the destination in EEPROM is undefined in general).</i></p>		
PROGRAM=1		
PSW	PS Window	
<p>Returns actual Program Service name that is being sent by the RDS encoder. The value returned is an output of internal real-time RDS decoder so it's affected also by Dynamic PS and user defined groups.</p>		
PSW		
Rabbbb,cc	Read Memory	
<p>Returns the encoder's memory content in HEX representation.</p> <p>a - memory type: 0 for RAM, 1 for device config, 2 for EEPROM</p> <p>bbbb - start address in the memory for reading (0000 to FFFF)</p> <p>cc - length of the block read in bytes (01 to 7E)</p>		
R00000, 02 Get current PI		
R00DD0, 20 Get current RDS group statistics (0A, 0B, ... 15B)		
RTP	Radiotext Plus Tagging Data	(00-31; 00-31; 00-31; 00-31; 00-31; 00-15)
<p>Six 2-digit decimal numbers of RT+ tagging data in this order:</p> <p>Tag 1 type, tag 1 start, tag 1 length, tag 2 type, tag 2 start, tag 2 length.</p> <p>Start marker 00 means the first character in the Radiotext. Length marker gives the number of characters following the first character at the start position.</p> <p>The tagging data must be associated with current Radiotext 1.</p> <p>The tagging data are transmitted as groups 3A (RT+ ODA AID) and 11A (RT+ Tagging Data).</p> <p>On each enter of the tagging data internal Toggle bit automatically changes its state from 0 to 1 or from 1 to 0.</p> <p>First entering of the tagging data automatically enables the internal RT+ feature until power off or reset.</p> <p>The RT+ is active only if symbol 'R' is present in the Group sequence.</p> <p>If both tag 1 type and tag 2 type are set to 00, internal RT+ running bit is temporarily hold low until at least one valid tag type is entered.</p>		
RT1=Now playing: Novaspace - Time After Time		
RTP=04, 13, 08, 01, 25, 14		
RTPRUN	Radiotext Plus Running Bit	(0, 1, 2)
<p>0 - Bit set low (RT1 no longer contains RT+ data), automatically set to 1 on next RTP= entry.</p> <p>1 - Bit set high (current RT1 contains RT+ data)</p> <p>2 - Disable internal RT+ feature</p> <p>This command is not required for common use since the running bit is set automatically.</p>		
RTPRUN=1		
SETSPY	Set RDS Monitoring Counter	
<p>This command is described in the document 'P132 RDS Encoders - Communication Ports and Internet Functions'.</p>		
SHORTRT	Short Radiotext	(0, 1)
<p>If enabled (1), all new inserted Radiotexts shorter than 60 characters will be followed by Carriage Return and the remaining spaces will be cut. Default value is 0.</p>		
SHORTRT=1		

SITE	Site List	(0-1023[,0-1023])
Up to two site address numbers in range 0 to 1023, separated by comma. Applies to UECP control.		
*SITE=16		
*SITE=125, 1022		
STORE	Write to the non-volatile RDS2 Buffer	
Syntax: *STORE=aaaa,rds group(s)		
aaaa: hexadecimal address in range B000 to EFFF. <i>Write to outside of this region may corrupt other RDS data.</i>		
rds group(s): array of hexadecimal byte values, each 8 bytes form one group. Max. length is 64 bytes.		
End of the buffer: If the data does not fill entire 16KB region available, a special sequence of 8 bytes must be stored behind the last RDS group. This terminating sequence is 0000FFFF00FF0000.		
See section 5.6.2 for details.		
*STORE=B000, 0000FFFF00FF0000 Clears the RDS2 buffer		
UDG1	User Defined Groups 1	
Specifies up to 8 groups in BBBBCCCCDDDD format, which are repeatedly transmitted in sequence by the RDS encoder. BBBB, CCCC and DDDD represent the contents of the block 2, block 3 and block 4 in hexadecimal expression. For more details about the group coding see section 10.2.		
When entering new group(s), previous groups are removed from the UDG1 buffer.		
UDG1=80001A961C97 Sets TMC group 8A containing 00 1A96 1C97		
UDG1= Clears the UDG1 groups		
UDG2	User Defined Groups 2	
Specifies up to 8 groups in BBBBCCCCDDDD format, which are repeatedly transmitted in sequence by the RDS encoder. BBBB, CCCC and DDDD represent the contents of the block 2, block 3 and block 4 in hexadecimal expression. For more details about the group coding see section 10.2.		
When entering new group(s), previous groups are removed from the UDG2 buffer.		
UDG2=380215D1A531, 38058DB3B61E Sets two UDG2 groups		
UDG2= Clears the UDG2 groups		
UECP	General UECP Enable	(0, 1)
Enables (1) or disables (0) the UECP support for all ports. ASCII commands are accepted regardless of this value.		
UECP=1		
XCMD	X-Command for RDS encoders	
This command is described in the document 'X-Command for RDS encoders'.		
XCMD=<rds><item><dest>3</dest><text>Now playing: <artist>Raw Spirit</artist> - <title>Back In Town</title></text></item></rds>		
Updates RT1 and RT+ with specified text and tags.		

7.9 Memory Organization



7.10 Dynamic PS 1 and Dynamic PS 2 Summary

	Dynamic PS 1	Dynamic PS 2
Real time showing capability	yes, in mode 0 and 2	yes, in mode 0 and 2
Display modes available	4	4
Text queue available	yes	no
Max. text length	255	255
Max. queued text length	127	N/A
Removing redundant spaces from the text end	yes, in mode 2 and 3	no
Allows transmission of Messages	no	yes
Typically used for	Commercials, news and "on-air" texts	Fixed texts from the <i>Messages</i> bank

8 Further Features

8.1.1 Bypass Relay

The RDS encoder board includes a bypass relay providing an alternative way for the MPX signal on power supply failure (applies to loopthrough connection mode only).

8.1.2 Program Set Input on the Board

On-board program input allows selecting one of two program sets by an external device. That device can be a simple switch or a device with digital (TTL) output. The `PROGRAM` parameter must be set to 0 to enable this feature. The program input is level controlled, the switch shut-off or logical 1 selects the Program set 1, the switch closure to ground or logical 0 selects the Program set 2.

Alternatively the on-board input can be used for selecting a text message or for control of other RDS service or setting. For more details see chapter 7.8 - Conditional Command.

8.1.3 TA/EON1TA Input on the Board

The TA/EON1TA input allows to control the Traffic Announcement parameter by an external device. That device can be a simple switch or a device with digital (TTL) output. The TA input is level or edge activated, as specified by the `TATMOUT` command.

- If level controlled, the switch closure to ground or logic 0 activates the TA (sets to 1). The switch shut-off or logic 1 deactivates the TA (sets to 0).
- If edge activated, a falling edge (logic 1 to logic 0 transition) activates the TA. Then the TA is deactivated after the duration specified by the `TATMOUT` command. Optionally a rising edge may deactivate the TA if occurs first.

The `TATMOUT` command doesn't affect the EON1TA switching. If EON1TA is controlled using the input on the board, the control is always based on the level.

The input function table:

TP (local)	EON1 Enabled	Input function
1	don't care	TA
0	1	EON1TA
0	0	Input disabled

8.1.4 Showing Real Time in Dynamic PS

It's possible to show real time in Dynamic PS in mode 0 and 2. To show the time, the text must contain `%HH-MM%` string and this string must exactly fill the 8-character window. Then on each string occurrence the real time will be displayed. The separator between hours and minutes is user selectable.

8.1.5 Real-Time Clock Backup

A battery-powered RTC circuit provides real-time backup for case of mains power supply interruption or switch off. Use `TIME` and `DATE` commands to set the time and date information or simply use the Windows control software.


8.1.6 Firmware Upgrade

The RDS encoder has a firmware upgrade capability. This allows easily implementing of new features in future. When a new firmware version is released, special simple Windows application provides the firmware upgrade. The firmware upgrades are provided at no costs. Please refer to the website for more information.

8.1.7 RDS Output Monitoring

Want to see or verify the RDS and RDS2 output data? The encoder supports direct complete RDS output monitoring on any communication port in real time using a desktop application. This unique feature allows complete RDS output analysis without need of a receiver or special equipment.

RDS data is provided as ASCII coded RDS groups in raw format at the RDS group rate (11.4 groups per second for each stream). The group content provided is equal to the group content being sent to output of the RDS encoder and being seen by listeners. This format of data is directly supported by some easy to use applications (for example freeware RDS Spy).



RDS Spy - Real-time freeware Radio Data System decoder and analyzer for Windows.

Monitoring the RDS Output Step-by-Step

1. For monitoring via Port 1, set the port speed to **19200 bps**.
2. In the Windows control software, select the device (connection) of interest.
3. Click on the RDS Spy button:



4. The real-time RDS content will appear immediately.

8.1.8 Dynamic Group Sequence

The device supports Group sequence and its proprietary extension called 'Dynamic group sequence'. Whereas the Group sequence assigns fixed channel capacity (data rate) to each RDS service, the Dynamic group sequence temporarily changes this assignment to provide more capacity for prioritized RDS service.

In current implementation, if the Dynamic group sequence is enabled, it temporarily doubles the 2A group rate when the Radiotext changes. As the result, the Radiotext updates much faster on receivers, compared to conventional RDS encoders. In the rest of the time, the bandwidth reserved for other RDS services is kept unaffected, according to the Group sequence.

The Dynamic group sequence can be enabled by following methods:

In the Windows control software, go to Device Setup – Special – Special Features.

Or in the terminal, type `SETFEAT=+0001`

8.1.9 On-line Support

Not sure how to set-up the unit? Some RDS related feature is missing?

Feel free to contact us at <https://pira.cz/forum/> or via email.

Important note: Before sending an email please make sure you have read entire content of this manual (incl. section 10.4), control software help file and also Technical forum, F.A.Q. and tips on the website. Your question may be already answered in this extensive knowledge base.

9 Universal Encoder Communication Protocol (UECP)

The UECP protocol (SPB 490) is an industrial standard for RDS encoder control to facilitate inter-working of various RDS devices and components regardless of the supplier. Due to rapid development of the field, the UECP typically does not handle specific functions and characteristics of particular RDS encoder model. Rather than this, it defines common interface for classic RDS services whereas other services have been set in advance using the way described on previous pages.


The UECP implementation in the P164 covers all commonly used services. Some UECP commands and functions that are obsolete, rarely used or not complying with the P164 concept, are not implemented.

9.1 UECP Implementation

9.1.1 To turn-on the UECP support

1. Configure all RDS services and settings as desired.
2. Where required, configure the RDS Encoder address and Site address using the commands `*ADR=` and `*SITE=` or using the Windows control software (RDS Encoder – Device Setup).
3. Find out and set the right baudrate (speed) or network settings of the RDS encoder's port.
4. The UECP support is enabled by default. In other cases, type `UECP=1` and `*UECP` or use the Windows control software to turn-on the UECP support.

9.1.2 General UECP frame (record) format



Note: Read more information about the UECP in the document "SPB 490 Universal Encoder Communication Protocol" (published by RDS Forum).

9.1.3 UECP addressing

The address field of each UECP record comprises of two elements. These are:

- Site address, 0-1023 (most significant 10 bits)
- Encoder address, 0-63 (least significant 6 bits)

The RDS encoder incorporates two address lists; one of acceptable Site addresses (`SITE`) and the other of acceptable Encoder addresses (`ADR`). A UECP record is acceptable to a particular encoder only if the site address is contained within its site address list and the encoder address is contained within its encoder address list.

It is expected that many UECP commands will be sent to all encoders. For this reason a "global" address of 0 is defined for both the site and encoder addresses. Thus the address lists always consist of addresses defined by user and the "global" address of 0. Messages bearing the site address of 0 are deemed to be acceptable at all sites in the system. Messages bearing the encoder address of 0 are deemed to be acceptable by all encoders at sites specified by the accompanying site address.

9.1.4 The UECP implementation in the P164

List of UECP commands accepted:

MEC	Meaning	Notes
01	PI	
02	PS	
03	TA/TP	
04	DI/PTYI	
05	MS	
07	PTY	
0A	RT	1
0D	Real time clock	
13	AF	
1C	Data set select	
24	Free-format group	3, 4
25	IH	3, 4
2D	Manufacturer specific command (X-Command)	
30	TMC	3, 5
40	ODA configuration and short message command	
42	ODA free-format group	3, 7
46	ODA data	3, 7

Special fields in the UECP frame:

Field	Handling
ADD	Site address 0-1023, Encoder address 0-63, note 2.
SQC	Sequence counter - if consecutive UECP records have the same SQC value, only the first correctly received record is applied. Except exists for records with SQC of 0x00 which are always accepted.
MFL	Message field length - In order to maintain overall robustness the MFL value must be exact, otherwise the UECP frame is considered as corrupted and it's discarded!
DSN	DSN must be 0 <u>or</u> 255 <u>or</u> equal to the number of current program set. Otherwise the command is discarded.
PSN	PSN must be 0 <u>or</u> equal to the PSNMAIN parameter of current program set <u>or</u> equal to any of the EON PSN in current program set. Otherwise the command is discarded.
CRC	If CRC does not match, the UECP frame is considered as corrupted and it's discarded.

Notes:

- 1) Capacity up to two Radiotexts.
- 2) The RDS encoder address list can contain up to three items for the Site address and up to seven items for the Encoder address. One of these items is always fixed to 0, the remaining items can be changed using the commands *SITE= and *ADR=.
- 3) Buffer size 16 groups (FIFO type), shared by all ODA data, IH, TMC and free-format Message elements. Number of repeats is assigned to each group in the FIFO buffer so one group occupies one position in the buffer regardless of number of repeats. See section 9.1.5.
- 4) Buffer configuration bit 5 ignored. Buffer configuration bit 6 meaning: 0 - no repeat, 1 - repeat the group one time, then clear.

- 5) Full support except the priority and buffer configuration. The encoder automatically assures at least 3-group long gap between any TMC groups in the data transmitted.
- 6) Timeout and buffer configuration ignored. Always inserts one group through the FIFO buffer.
- 7) Priority, mode and buffer configuration ignored. Always inserts one group through the FIFO buffer ("immediate" priority).

When the UECP is enabled, the RDS encoder accepts any mixture of ASCII commands and UECP records on the same communication port. The UECP communication is always unidirectional. There are no responses sent to the UECP records.

Any characters which follow the UECP start byte (0xFE) will be ignored by the ASCII command interpreter until one of the following conditions occurs:

- reception of the UECP stop byte (0xFF)
- reception of up to 260 characters
- port timeout (2 minutes)

For this reason take care not to send the UECP start byte within an ASCII command when the UECP is enabled.

9.1.5 UECP buffer for user-defined RDS groups

In order to simplify the RDS encoder's control and fit it to current applications, the device incorporates one global UECP buffer for all groups inserted via MEC 24, 25, 30, 42 and 46. This buffer is a FIFO type and its capacity is 16 groups.


Transparent UECP buffer

If there's no symbol 'U' in the Group sequence, the UECP buffer is flushed into output stream as soon as possible, taking higher priority above any other group (excluding time groups 4A generated by the RDS encoder). This is a default configuration.

Batch UECP buffer

If there's at least one symbol 'U' present in the Group sequence, the buffer inserts one group into the output stream on the occurrence of the 'U' symbol. This makes a possibility to limit the speed of the buffer flushing but the groups may be delayed on the output.

The UECP buffer scheme is as follows (simplified):



Note: The UECP buffer applies only to user-defined RDS groups inserted via UECP protocol. The UECP buffer has no meaning for other than those UECP MECs: 24, 25, 30, 42, 46 and 40 (single transmission).

9.2 Traffic Message Channel (TMC) Application Notes

9.2.1 Basic requirements

The TMC service can work only if there is an application that we can call 'TMC data provider'. The TMC data provider collects all related information and translates it into RDS groups 8A type. The output from the TMC data provider is typically coded into UECP commands (MEC) 40 and 46 or into UECP command (MEC) 30. We will deal with the last case in following text.

Nowadays the TMC service is coded as an ODA application. Thus there must be ODA AID groups 3A transmitted in addition to the 8A groups. This can be done for example using the UECP MEC 40 or 24. The 3A groups typically carry fixed content so in some cases they can be inserted into the RDS encoder also one-time using the command UDG1= or UDG2=.

The Address and Site fields are optional. When the TMC data provider drives one RDS encoder only, these fields are usually set to zero. However there can be more RDS encoders connected with various Address and Site values. Each encoder will accept only the UECP records that match the Address and Site criteria. This configuration has been tested successfully simulating a network of more than 60 encoders (equivalent to full load of one 9600 bps channel).

9.2.2 Preparing for the TMC transmission

1. Configure all static parameters of the RDS encoder (PI, PS, CT etc.). Enable the UECP (UECP=1, *UECP,).
2. Where required, store the fixed 3A groups using the commands UDG1= or UDG2= (for example: UDG1=30100646CD46, 30104080CD46, *UDG1,).
In this case make sure the UDG groups are included in the Group sequence (symbols X or Y).
3. Decide for the communication settings. Configure the RDS encoder and TMC data provider ports.
4. Configure the Site and Address values.

9.2.3 Application example

This application example shows TMC data and ODA AID information inserted by UECP commands 30 and 24.

Time	Group	UECP command	Comment
...			
9:27:58	3A: 8A 0646 CD46	FE 00 00 D0 07 24 06 10 06 46 CD 46 B9 68 FF	ODA AID variant 0
9:27:58	8A: 07 C801 4689	FE 00 00 D1 08 30 06 06 07 C8 01 46 89 94 54 FF	TMC 8A, two repeats
9:27:59	8A: 07 4984 6000	FE 00 00 D2 08 30 06 06 07 49 84 60 00 F2 5C FF	TMC 8A, two repeats
9:27:59	3A: 8A 4080 CD46	FE 00 00 D3 07 24 06 10 40 80 CD 46 49 7E FF	ODA AID variant 1
9:28:00	-	FE 00 00 D4 09 0D 0A 0C 10 09 1C 00 00 02 60 F3 FF	Encoder real time adjust
9:28:00	8A: 01 883D 1A74	FE 00 00 D5 08 30 06 06 01 88 3D 1A 74 5F DC FF	TMC 8A, two repeats
9:28:00	3A: 8A 0646 CD46	FE 00 00 D6 07 24 06 10 06 46 CD 46 E3 E0 FF	ODA AID variant 0
9:28:01	8A: 02 8F50 15DD	FE 00 00 D7 08 30 06 06 02 8F 50 15 DD D3 6E FF	TMC 8A, two repeats
9:28:01	8A: 02 5404 ABD4	FE 00 00 D8 08 30 06 06 02 54 04 AB D4 1D E6 FF	TMC 8A, two repeats
9:28:01	3A: 8A 4080 CD46	FE 00 00 D9 07 24 06 10 40 80 CD 46 A6 E6 FF	ODA AID variant 1
9:28:02	8A: 05 497C 8000	FE 00 00 DA 08 30 06 06 05 49 7C 80 00 A6 D5 FF	TMC 8A, two repeats
...			

Notes:

- 1) Any RDS group inserted using the UECP elements 24, 25, 30, 40, 42 or 46 is put into the UECP buffer. See section 9.1.5 for more details. For TMC transmission it is recommended to leave the UECP buffer as transparent so the TMC data providing application has full control over the TMC transmission. The encoder automatically ensures at least 3-groups long gap between TMC groups.

10 Annexes

10.1 Character Set and Code-Table Conversions

Original RDS system, as defined by the standards, does not support Unicode character set. Default character set (G0) used within the RDS system is limited to the characters provided in following EBU Latin code-table.

0x	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0	0	@	P	`	p	á	â	ª	º	Á	Â	Ã	ã		
1	!	1	A	Q	a	q	à	ä	α	¹	À	Ä	Å	å	
2	"	2	B	R	b	r	é	ê	©	²	É	Ê	Æ	æ	
3	#	3	C	S	c	s	è	ë	‰	³	È	Ë	Œ	œ	
4	◊	4	D	T	d	t	í	î	Š	±	Í	Î	ÿ	ŵ	
5	%	5	E	U	e	u	ì	ï	š	İ	Ì	Ï	Ý	ý	
6	&	6	F	V	f	v	ó	ô	ñ	´	Ó	Ô	Õ	õ	
7	'	7	G	W	g	w	ò	ö	ö	ı	Ò	Ö	Ø	ø	
8	(8	H	X	h	x	ú	û	π	μ	Ú	Û	Ð	þ	
9)	9	I	Y	i	y	ù	ü	€	ı	Ù	Ü	Ɔ	ƞ	
A	*	:	J	Z	j	z	Ñ	ñ	£	÷	Ř	ř	Ŕ	ŕ	
B	+	;	K	[k	{	Ç	ç	\$	°	Č	č	Ć	ć	
C	,	<	L	\	l		Ş	ş	←	¼	Š	š	Ś	ś	
D	-	=	M]	m	}	β	β	ğ	↑	½	Ž	ž	Ž	ž
E	.	>	N	^	n	~	ı	ı	→	¾	Đ	đ	Ʀ	Ʀ	
F	/	?	O	_	o		IJ	ij	↓	§	Ł	ł	ð		

Basic set
Extended set

Example of use:

Character 'é' can be found in the table on coordinates 8, 2. Thus it converts to ASCII character 0x82 (HEX) or 130.

A conversion is required for all characters outside the basic set region. If you use the Magic RDS control software, the characters are converted automatically between Windows Unicode and RDS character set. Setting for that feature can be made in Preferences - Local settings. Some functions are based on UTF-8 coding - conversion is made automatically inside the RDS encoder.

Notes:

- Many commercially available receivers use 14-segment LCD displays. These receivers are able to display only a limited part of the basic character set (green framed) and do not support the extended set at all. All lower-case characters are showed as upper-case.
- The EBU Latin basic set is compatible with most of other systems so conversion is not required for this region.
- Since many receivers contain no support for the extended character set, it is recommended to keep all characters in all text messages in the basic set region.


10.2 RDS Group Format

Following information is provided for better understanding to the RDS principles and the user defined group coding.

The largest element in the RDS coding structure is called a "group" of 104 bits each. Each group comprises 4 blocks of 26 bits each. Each block comprises an information word and a checkword. Each information word comprises 16 bits. Each checkword comprises 10 bits.

All information words, checkwords, binary numbers or binary address values have their most significant bit (MSB) transmitted first.

The data transmission is fully synchronous and there are no gaps between the groups or blocks. The basic data-rate of the system is 1187.5 bit/s. Thus transmission of one group takes about 87.6 ms and about 11.4 groups are transmitted per one second.



General RDS group format.


10.2.1 Basic principles and rules

- The services which are to be repeated most frequently, and for which a short acquisition time is required (PI, TP, PTY), in general occupy the same fixed positions within every group.
- There is no fixed rhythm of repetition of the various types of group, i.e. there is ample flexibility to interleave the various kinds of message to suit the needs of the users at any given time.
- The first four bits of the second block of every group are allocated to a four-bit code which specifies the application of the group - group type. Groups are referred to as types 0 to 15.
- For each type (0 to 15) two "versions" can be defined. The "version" is specified by the fifth bit of block 2: 0 = version A, 1 = version B.
- For all groups of version B the PI is inserted also in block 3 so this block cannot carry any other information when version B of the group is used.

10.2.2 Remarks

- One complete PS label consists of 4 groups. So one PS takes 350 ms of the transmission time. It may be found from experience that any RDS text should be transmitted at least twice to improve reception reliability. With regard to other services included in the RDS the repetition rate of dynamic/scrolling PS usually cannot be lower than one second.
- Checkwords and offsets are always computed and inserted automatically by the RDS encoder.
- PI is always inserted automatically by the RDS encoder in block 1, and also in block 3 for version B of the group. Due to this the block 1 is never specified when inserting any user defined group.
- TP and PTY are always inserted automatically by the RDS encoder using OR method (logical sum) on the appropriate bit positions.

10.2.3 TDC group coding (5A, 5B)




Group format in hexadecimal representation (version A): 50BBCCCCDDDD,

group format in hexadecimal representation (version B): 58BB0000DDDD,

where BB, CCCC and DDDD represent the contents of the block 2 (bits 4 to 0), block 3 and block 4.

10.2.4 IH group coding (6A, 6B)




Group format in hexadecimal representation (version A): 60BBCCCCDDDD,

group format in hexadecimal representation (version B): 68BB0000DDDD,

where BB, CCCC and DDDD represent the contents of the block 2 (bits 4 to 0), block 3 and block 4.

10.2.5 AID for ODA group coding (3A)



Group format in hexadecimal representation: 30BBCCCCDDDD,

where BB, CCCC and DDDD represent the contents of the block 2 (bits 4 to 0), block 3 and block 4.

These groups are used to identify the Open Data Application in use, on an RDS transmission. The type 3A group conveys, to a receiver, information about which Open Data Applications are carried on a particular transmission (AID Code) and in which groups they will be found (Application group type code).

The Application group type code and the AID Code are obligatory, while the Message field is optional and should be set to zeros if not used.


Since the 3A groups usually carry fixed static content, they may be inserted using either the UDG1= or UDG2= command for automatic cyclic transmission while the ODA application groups may be inserted by any command or method (G=, UDG1=, UDG2= or UECP MEC 24 or 42).

10.2.6 Example of ODA user defined group coding (Radiotext Plus)

Let's show the group coding example on the popular RT+ service. We need to insert group type 3A (Application identification for ODA) to the RDS stream pointing to the RT+ service which is - in this example - carried in group 11A.

Let's assume following RT content: Enigma - The Eyes of Truth

Appropriate 3A and 11A groups have following structure and coding:



Let's assume following variable values:


AGT: group type 11, version A (0), rfu: reserved, set as zeros, CB flag: 0, SC flag: 0, TN: N/A, set as zeros, AID code is 4BD7 for the RT+ service.

Blocks 2 to 4 in binary representation:

0011 0000 0001 0110 | 0000 0000 0000 0000 | 0100 1011 1101 0111

Blocks 2 to 4 in hexadecimal representation:

3016 | 0000 | 4BD7



Let's assume following variable values:

AGT: group type 11, version A (0), ITG: 0, IRB: 1, RTCT1: 1 (Title), SM1: 9 (10th RT character), LM1: 16 (17 characters long), RTCT2: 4 (Artist), SM2: 0 (first RT character), LM2: 5 (6 characters long).

Blocks 2 to 4 in binary representation:

1011 0000 0000 1000 | 0010 0100 1010 0000 | 0010 0000 0000 0101

Blocks 2 to 4 in hexadecimal representation:

B008 | 24A0 | 2005

Inserting the RT+ groups using the UDG1 command:

UDG1=301600004BD7,B00824A02005

Note:

This example is for illustration only. The RT+ feature is directly supported by the RDS encoder (see section 5.1.2).

10.3 Installation Essential Checklist

This is a list of points to consider *before* leaving the site of final installation. The list applies to Ethernet control.

<input type="checkbox"/>	All cables and connectors are seated completely	4.1
<input type="checkbox"/>	The PILOT LED indicates pilot tone Applies to stereo broadcast only.	3.1
<input type="checkbox"/>	The LOOP/SIDE switch is in correct position Incorrect position will result in either distorted stereo or audio getting silent.	4.2.2
<input type="checkbox"/>	The RDS level has been adjusted	4.5.1
<input type="checkbox"/>	The audio is clean and completely unaffected	4.1 4.2.2 4.5.1
<input type="checkbox"/>	The device is operating and communicating via Ethernet	3.1 4.4
<input type="checkbox"/>	The device IP address is either fixed or reserved If the IP address is assigned by DHCP, configure IP address reservation in the router.	6.3
<input type="checkbox"/>	The Inactivity timeout or Port 2 fail-safe monitor is enabled	6.3
<input type="checkbox"/>	The RDS reception works OK on a receiver	
<input type="checkbox"/>	The setup is still correct after reset Recycle the power of the RDS encoder and of the network router to check that all settings are permanent and the operation resumes correctly.	

Date of installation:

RDS level:

Local IP address:

Site IP address:

Notes:

10.4 Troubleshooting

The RDS encoder has been designed to make its use as easy and painless as possible. However, success depends upon a number of settings and things working together correctly. While correcting problems is usually quite simple, the difficulty lays in knowing where to look.

Factory default settings assure right operation after first power-on. This section of the manual is designed to assist you in determining the cause of problems that may occur so they can be fixed quickly.

Problem	Section related	Solution / Check	
		Windows control software	Terminal
No RDS output, no LED indication.	4.3	Power supply problem.	
No RDS output, but LED indicates operation.	4.1 4.5.1	RDS output connected to right input of the transmitter? Adjust higher RDS level or higher input sensitivity on the transmitter. RDS generator switched on?	
		Device Setup - Analog Control - RDS Generator	RDSGEN=1
The unit does not communicate with PC and the LED does not indicate data receive.	4.4 6.1	Make sure all connectors are seated completely. Make sure you have selected right COM port.	
		Connection - Edit connection...	
		Try the unit with different cable and different PC.	
The unit does not communicate with PC but the LED indicates that data is received.	4.4 7.6 6.3.5	<ul style="list-style-type: none"> Port baudrate differs from the device configuration. Address does not match (applies to UECP only) 	
		Enable Bidirectional and Autodetect port speed options (Connection - Edit connection...) Device Setup - Communication - Options - Port 1 Speed	Try typing any command on each baudrate.
Radiotext stopped working although I'm sure that it's enabled and entered correctly.	7.8	The RT service is not included in the Group sequence. Initialize the Group sequence to its default value.	
		RDS Content - System - Group sequence - Default, Test, Apply.	GRPSEQ=
Pilot tone is fed to the unit but it is not indicated.	4.1	Device Setup - Analog Control - Reference Source: Auto	EXTSYNC=1
The unit loses time and date after power off.	3.3	Replace the battery on the board.	
The audio is distorted. There is a whistling in the audio.	4.1 4.2.2 4.5.1	<ul style="list-style-type: none"> The unit is not connected in loopthrough mode but the loopthrough switch is in the LOOP position. Switch to the SIDE position. The RDS level considerably exceeds maximum value allowed. Adjust lower RDS level. Use an FM analyzer for the best result. Applied input of the transmitter is not suitable for RDS. Follow the transmitter's documentation. Power supply failure. 	
No audio on air	4.1 4.2.2	The unit is connected in loopthrough mode but the loopthrough switch is in SIDE position. Switch to the LOOP position.	