


PIRA32 Module Mechanical Data



* RDS level trimmer placed horizontally (top side or bottom side control)

** RDS level trimmer placed vertically (front panel control)

All dimensions are in [mm]